

Inverter



# i500

Inverter i510 / i550 - Cabinet

Operation Manual

EN

# PRELIMINARY

SW-Version 02.01

**Lenze**

## Contents

<b>1</b>	<b>About this manual.....</b>	<b>6</b>
1.1	Purpose of this manual.....	6
1.2	Storage place.....	6
1.3	Reference to other documents .....	6
1.4	Copyright .....	6
1.4.1	Manufacturer's address .....	6
1.5	Disclaimer of liability .....	6
1.6	Parameter description.....	7
<b>2</b>	<b>Safety information .....</b>	<b>8</b>
2.1	Intended use of inverter.....	8
2.2	Examples of unintended use .....	8
2.3	Qualified personnel .....	8
2.4	Signal words and symbols .....	8
2.4.1	Elements of a safety message .....	9
2.5	Warning labels on inverter .....	9
2.6	Basic safety measures .....	10
2.7	Electromagnetic influences .....	11
2.8	Residual hazards .....	11
<b>3</b>	<b>Product description.....</b>	<b>12</b>
3.1	General .....	12
3.1.1	i500 inverter types .....	13
3.2	Overview .....	14
3.2.1	i510 inverter overview .....	14
3.2.2	i550 inverter overview .....	15
3.3	Typecode .....	16
<b>4</b>	<b>Installation.....</b>	<b>17</b>
4.1	Mechanical installation .....	17
4.2	Electrical installation .....	17
4.2.1	Wiring overview i510 .....	18
4.2.2	Wiring overview i550 .....	19
4.2.3	Control wiring i510/i550 .....	20
4.2.4	Default control setup .....	21
<b>5</b>	<b>Commissioning.....</b>	<b>22</b>
5.1	Set-up tools .....	22
5.1.1	Overview .....	22
5.1.2	Keypad .....	23
5.1.3	Easy Starter & USB adapter.....	27
5.2	Commissioning procedure.....	28
5.4	General parameter setup (Favorites) .....	29
5.4.1	Diagnostic.....	29
5.4.2	Basic setup .....	29

5.4.3	Motor control modes .....	30
<b>6</b>	<b>Function &amp; parameter description .....</b>	<b>34</b>
6.1	Parameter / function overview.....	34
6.2	Control concept .....	36
6.2.1	Setpoint structure / operation mode .....	36
6.2.2	Control Source.....	38
6.2.3	Control examples.....	39
6.2.4	Rotation direction.....	42
6.3	Group 1 – Diagnostics .....	43
6.3.1	General Diagnostic Data.....	43
6.3.2	Output Power .....	44
6.3.3	Output Energy .....	44
6.3.4	Analog Input 1 Diagnosis .....	44
6.3.5	Analog Input 2 Diagnosis .....	44
6.3.6	Analog Output 1 Value .....	44
6.3.7	Analog Output 2 Value .....	45
6.3.8	Heatsink temperature .....	45
6.3.9	I/O Status.....	45
6.3.10	Process Controller Diagnosis .....	45
6.3.11	Motor protection i2xt.....	46
6.3.12	Control / Setpoint Source .....	46
6.3.13	Inverter status .....	46
6.3.14	Device utilization (ixt).....	47
6.3.15	Error code.....	47
6.3.16	Timer / Counter .....	47
6.3.17	History Buffer .....	48
6.3.18	Device data .....	48
6.3.19	Device Name .....	49
6.3.20	Device Module.....	49
6.3.21	Additional status.....	49
6.4	Group 2 – Basic setup .....	49
6.4.1	Default control source.....	49
6.4.2	Default setpoint.....	50
6.4.3	Keypad setpoints .....	51
6.4.4	Start and Stop configuration .....	51
6.4.5	Start on power up.....	52
6.4.6	Voltage configuration .....	53
6.4.7	Min/Max frequency.....	53
6.4.8	Acceleration / Deceleration.....	54
6.4.9	Quickstop ramp time (QSP) .....	55
6.5	Group 3 – Motor control.....	56
6.5.1	Motor control mode.....	56
6.5.2	V/f: Curve setting.....	59
6.5.3	V/f: Slip compensation .....	60
6.5.4	V/f: Frequency boost .....	60
6.5.5	V/f: Oscillation damping .....	60
6.5.6	V/f: Override point of field weakening .....	60
6.5.7	Rotation restriction .....	61
6.5.8	Switching frequency .....	61
6.5.9	Motor thermal overload (i2xt) .....	62
6.5.10	Motor temperature sensor .....	63

6.5.11	Skip frequency.....	64
6.5.12	Motor parameter .....	65
6.5.13	Speed limitation.....	66
6.5.14	Current limitation.....	66
6.5.15	Torque limitation .....	67
6.5.16	HTL Encoder setup .....	67
6.5.17	Overspeed monitoring .....	68
6.5.18	Overcurrent monitoring.....	68
6.6	Group 4 – I/O setup.....	69
6.6.1	Function list (Run/Stop/Start/Jog/Reverse) .....	69
6.6.2	Setpoint selection .....	73
6.6.3	Motor Potentiometer .....	74
6.6.4	User defined faults.....	75
6.6.5	Digital input configuration .....	75
6.6.6	Frequency threshold setup .....	76
6.6.7	Digital output configuration.....	76
6.6.8	Analog input settings .....	78
6.6.9	Analog output settings.....	80
6.6.10	Preset setpoints (Frequency, PID).....	82
6.7	Group 5 – Fieldbus.....	83
6.8	Group 6 – PID setup.....	83
6.8.1	PID Setup.....	83
6.8.2	PID triggers.....	85
6.8.3	PID Setpoint limits.....	85
6.8.4	PID Acceleration / Deceleration.....	85
6.8.5	PID Influence .....	86
6.8.6	PID Alarms.....	86
6.8.7	PID Sleep/Rinse function.....	86
6.9	Group 7 – Auxiliary Functions .....	87
6.9.1	Device functions (Factory reset, load/store parameter) .....	87
6.9.2	Keypad setup.....	88
6.9.3	DC brake setup.....	88
6.9.4	Regenerative energy management.....	90
6.9.5	Loss of Load Detection .....	93
6.9.6	Motor Brake Control .....	93
6.9.7	Access protection .....	93
6.9.8	Favorites setup.....	94
6.9.9	Multiple Parameter Set Setup.....	94
<b>7</b>	<b>Fieldbus .....</b>	<b>95</b>
7.1	CANopen quick start.....	96
7.2	Modbus quick start.....	99
7.3	Profibus quick start.....	101
<b>8</b>	<b>Drive Profile (Fieldbus).....</b>	<b>103</b>
8.1	CIA402 .....	104
8.1.1	Control word .....	104
8.1.2	Status word .....	105
8.1.3	Speed setpoint / Actual Speed .....	105
8.2	Legacy Lenze Format .....	106
8.2.1	Control word C135 .....	106

---

8.2.2	Status word .....	107
8.2.3	Speed setpoint / Actual Speed .....	108
8.3	AC Drive Profile .....	109
8.3.1	Control word .....	109
8.3.2	Status word .....	110
8.3.3	Speed setpoint / Actual Speed .....	111
8.4	NETword Configuration .....	112
8.4.1	NETWordIn configuration.....	113
8.4.2	NETWordOut configuration.....	115
<b>9</b>	<b>Troubleshooting .....</b>	<b>117</b>
9.1	LED status display .....	117
9.2	CAN LED status display .....	117
9.3	Modbus LED status display .....	118
9.4	Profibus LED status display .....	118
9.5	Error history .....	119
9.5.1	Error History Keypad .....	119
9.5.2	Error History Easy Starter .....	120
9.6	Error messages.....	120
<b>10</b>	<b>Maintenance .....</b>	<b>125</b>
10.1	Routine inspections .....	125
10.2	Product support.....	125
<b>11</b>	<b>Decommissioning .....</b>	<b>126</b>
11.1	Safety instructions .....	126
11.2	Removal and disposal .....	126

## **1 About this manual**

Purpose of this manual

---

# **1 About this manual**

This manual

- applies to the i500 inverter series,
- contains important technical information for the commissioning and operation of the i500,
- explains the most important parameters and settings for the commissioning of standard applications.

## **1.1 Purpose of this manual**

The purpose of this manual is to provide all necessary information for the installation, commissioning, start-up and troubleshooting of i500 inverters. It is also intended as a planning aid and reference for drive configurations. Reading and understanding this manual is therefore a basic requirement for all engineers and commissioning technicians/electricians working with i500 inverters in their applications, machines and systems.

## **1.2 Storage place**

The operation manual must be stored such that it can be easily accessed by all persons working on the inverter.

## **1.3 Reference to other documents**

Beside the operation manual the following documents are also required for the safe installation, commissioning and operation of the inverter:

- i500 Mounting and switch-on instructions
- i500 Reference/Commissioning manual
- i500 EthernetBus manual
- Easy Starter software documentation

## **1.4 Copyright**

© 2015 Lenze Drives GmbH

All rights reserved. All information and illustrations contained in this operation manual are the property of Lenze Drives GmbH and may not be used in any manner harmful to their interests.

### **1.4.1 Manufacturer's address**

Lenze Drives GmbH  
Postfach 10 13 52, D-31763 Hameln  
Breslauer Straße 3, D-32699 Extertal  
Germany  
HR Lemgo B 6478

Phone: +49 5154 82-0  
Fax: +49 5154 82-2800  
Email: [lenze@lenze.com](mailto:lenze@lenze.com)  
Web: [www.lenze.com](http://www.lenze.com)

## **1.5 Disclaimer of liability**

The descriptions, technical data and illustrations in this operation manual are subject to change without prior notice.

The procedural notes and circuit details described in this operation manual are only proposals. It is up to the user to check whether they can be adapted to the particular applications. Lenze does not take any responsibility for the suitability of the procedures and circuit proposals described.


## 1 About this manual

Parameter description

### 1.6 Parameter description

Every parameter has a hexadecimal index number. Parameters which are visible on the keypad have also a parameter number. In the Easy starter the parameter number and the hexadecimal index are visible. Every parameter can have subindex.

Example	Parameter number	Index
Base Frequency	P303.02	0x2B01:002
Control select	P200.00	0x2824:000



Parameter which are not visible on the keypad are marked in the manual as P (Without number)



Parameters or selections with marking (\*) are not available on all control unit types.

Example:

P510:1	0x23A1:1	IP address (*)		I550	R/V
-- ... [192.168.124.16] ... --		EtherNet/IP adress settings			

## 2 Safety information

Intended use of inverter

# 2 Safety information

## 2.1 Intended use of inverter

The i500 inverters are used for controlling low-voltage motors in industrial and commercial applications within the range of the inverter's technical specifications.

## 2.2 Examples of unintended use

- Commissioning of an i500 inverter in the event of visible damage or if its display shows any sign of damage.
- Commissioning of an i500 inverter that is not fully mounted.
- Illegal technical modifications or software modifications on an i500 inverter.
- Using accessories not approved for the i500 inverter.
- Operating an i500 inverter without necessary protecting covers or outside the technical specifications.
- Operating an i500 inverter in explosive atmosphere.



This list shows a few examples of unintended use, it is not complete and not limited to the examples stated.

## 2.3 Qualified personnel

Only qualified personnel according to relevant international and national standards may work on or with the inverter. The necessary skills of qualified persons are defined as follows:

- They have read and understand this operation manual.
- They are familiar with installing, mounting, commissioning, and operating the i500 inverter.
- They have the corresponding qualifications for their work.
- They know safe work procedures and lockout/ tagout procedures to create a safe work area.
- They know and can apply all regulations for the prevention of accidents, directives, and laws applicable at the place of use.

## 2.4 Signal words and symbols

The following symbol and signal words are used in this manual to indicate dangers and important information:



The safety alert symbol is part of a safety message and is used to alert to potential hazards.



**DANGER!**

**DANGER** indicates a hazardous situation which, if not avoided, will result in death or serious injury.



**WARNING!**

**WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.



**CAUTION!**

**CAUTION** indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

## 2 Safety information

### Warning labels on inverter

#### **(i) NOTICE!**

**NOTICE** indicates a situation which could lead to property damage.



This symbol indicates an important note or helpful advice to ensure trouble-free operation.



This symbol indicates a page reference or reference to another i500 manual.

#### 2.4.1 Elements of a safety message

##### **⚠ WARNING!**

##### **Dangerous electrical voltage**

Death or severe injuries.

- ▶ All works on the inverter must only be carried out in the deenergised state.

- ▶ ...

##### **◀ Safety alert symbol with signal word in color bar**

##### **◀ Type and source of danger**

##### **◀ Consequences of non-compliance**

##### **◀ Prevention measure(s)**

## 2.5 Warning labels on inverter




Fig. 1: i500 warning labels

Observe the following warning labels on the front side of the inverter:

Warning label	Description
	<b>Dangerous electrical voltage</b> Before working on the inverter, check whether all power connections are dead! After mains OFF, power connections X100 and X105 carry a dangerous electrical voltage for the time specified on the inverter! After switching off the mains voltage wait at least 180s before starting to work on the device.
	<b>High leakage current</b> Carry out fixed installation and PE connection in compliance with standard EN 61800-5-1 !

## 2 Safety information

### Basic safety measures

	<b>Hot surface</b> Use personal protective equipment or wait until inverter has cooled down!
Warning label	Description
	<b>Electrostatic sensitive devices</b> Before working on the inverter, the staff must ensure to be free of electrostatic charge!

## 2.6 Basic safety measures

### **WARNING!**

#### **Workplace hazards**

Possible death or severe personal injury.

- ▶ Observe all specifications of the corresponding documentation supplied. This is the precondition for safe and trouble-free commissioning and operation of the inverter and for obtaining the product features specified.
- ▶ Observe the specific safety instructions in this operation manual.
- ▶ Equip the inverter/drive system with additional monitoring and protection devices if required by national safety regulations.
- ▶ Commissioning of the inverter and the related drive system (i.e. starting of the operation as directed) is prohibited until it is proven that the machine complies with the regulations of the EC Directive 2006/42/EC (Machinery Directive); the standard EN 60204 must be observed.

### **WARNING!**

#### **Dangerous electrical voltage**

An electrical shock can cause death or severe personal injury.

- ▶ Apply lockout/tagout procedures whenever possible.
- ▶ Connect/disconnect all pluggable inverter connections only in deenergised condition!
- ▶ Only remove the inverter from the installation in completely deenergised state.

### **NOTICE!**

#### **Incorrect inverter installation**

Disregarding the following instructions may lead to inverter damage and damage to material assets:

- ▶ The inverter must be installed and cooled according to the instructions given in the "i500 Mounting and switch-on instructions". The ambient air must not exceed pollution degree 2 according to EN 61800-5-1.
- ▶ Ensure proper handling and avoid excessive mechanical stress. Do not bend any inverter components and do not change any insulation distances during transport or handling.

### **NOTICE!**

#### **Incomplete or faulty inverter parameterization**

Disregarding the following advices may lead to inverter damage and damage to material assets:

- ▶ Always check if the procedural notes and circuit details described in this document can be adapted to the particular application.
- ▶ Refer to the i500 Commissioning manual for the parameterization of technically sophisticated applications.

## 2 Safety information

### Electromagnetic influences

## 2.7 Electromagnetic influences

The i500 inverters can be installed in drive systems of category C2 according to EN 61800-3. These devices can cause radio interferences in residential areas. In this case, special measures can be necessary.

### NOTICE!

#### Possible electromagnetic interference of drive and control system

Sporadic malfunctions can cause unsafe operation conditions.

- ▶ Commissioning of the inverter and the related drive system (i.e. starting of the operation as directed) is only allowed when there is compliance with the EMC Directive (2004/108/EC).
- ▶ The inverter must be installed in a housing (e.g. control cabinet) to meet the limit values for radio interferences valid at the site of installation.

## 2.8 Residual hazards

Consider the following residual hazards in the risk assessment of the application.

### WARNING!

#### Unexpected drive motion

Possible personal injury or property damage.

If there is a short circuit of two power transistors in the inverter, a residual movement of up to  $180^\circ/\text{number of pole pairs}$  can occur at the connected motor! (For 4-pole motor: residual movement max.  $180^\circ/2 = 90^\circ$ ).

### WARNING!

#### Dangerous residual voltage – long discharge time!

An electrical shock can cause death or severe personal injury.

- ▶ After the inverter or the drive system has been disconnected from the supply voltage, all live components and power terminals must not be touched immediately because capacitors in the inverter can still be charged.
- ▶ Observe the waiting time on the inverter label.

### WARNING!

#### High leakage current

i500 inverters may cause a DC current in the PE conductor.

Possible personal injury due to inappropriate or insufficient protective measures.

- ▶ If a residual current device (RCD) is used for protection against direct or indirect contact for an inverter with three-phase supply, only a residual current device (RCD) of type B is permissible on the supply side of the inverter.
- ▶ If the inverter has a single-phase supply, a residual current device (RCD) of type A is also permissible.
- ▶ Apart from using a residual current device (RCD), other protective measures can be taken as well, e.g. electrical isolation by double or reinforced insulation or isolation from the supply system by means of a transformer.

### 3 Product description

#### General

## 3 Product description



Fig. 2: i500 inverter series

### 3.1 General

The i500 is a inverter series in the 0.25-45 kW power range. Its distinguishing features are:

- a streamlined design,
- scalable functionality
- exceptional user-friendliness.

i500 provides a high-quality inverter that conforms with the EN 50598-2 efficiency classes (IE). Overall, this provides a reliable inverter for a wide range of machine applications.

#### Highlights

- Streamlined design with a width of 60 mm up to 2.2 kW saves space in the control cabinet. Also the inverter fits to a 150 mm cabinet up to 11 kW.
- Innovative interaction options enable faster than ever setup times.
- The wide-ranging modular system enables various product configurations depending on machine requirements.
- i500 can be used for wide range of applications:  
Pumps and fans, conveyor, travelling, winding, shaper, tool and hoist drives...

### 3 Product description

#### General

---

##### 3.1.1 i500 inverter types

	i510	i550
<b>Performance data</b>		
Mains: 1 AC 230 V or (1/3 AC 230 V planed)	0.25 to 2.2 kW	0.25 to 2.2 kW
Mains: 3 AC 400/480 V	0.37 to 2.2 kW	0.37 to 45.0 kW (Planned up to 110.0 kW)
<b>Overload ability</b>	150% / 60s and 200% / 3s	
<b>Interfaces</b>	Digital inputs/outputs (5/1), analog inputs/outputs (2/1), relays (optional extension with i550)	
	External 24 V supply PTC thermal contact input HTL incremental encoder (100 kHz)	
	CANopen, Modbus	CANopen, Modbus, PROFIBUS, Ether-CAT, PROFINET, EtherNet/IP
	Integrated brake chopper DC bus connection (3 AC 400V devices)	
<b>Approvals</b>	CE, EAC UL & cUL (up to 22 kW, further approvals in progress) RoHS2, IE2 in accordance with EN 50598-2	
<b>Functions</b>	V/f controls (linear, quadratic) Sensorless vector control	
	DC injection Braking Compound Braking	
	Mechanical Brake management low-wear brake control	
	Dynamic braking through brake resistance	
PID controller, Motor potentiometer, Flying restart		
<b>Safety technology</b>	Safe torque off (STO)	

### 3 Product description

#### Overview

## 3.2 Overview

Get familiar with the two inverter types on the following overview images.

### 3.2.1 i510 inverter overview




Fig. 3: i510 inverter overview

#### Position numbers

- |  |  |
|--|--|
| 1) X3 – Control terminal (Basic I/O)     | 9) Rating plate                                |
| 2) X9 – Relay output                     | 10) Inverter status LEDs                       |
| 3) X16 – Interface for diagnostic module | 11) Network status LEDs                        |
| 4) X20 - Memory module                   | 12) PE / Ground connection                     |
| 5) X100 – Mains connection               | 13) Shield connection (CANopen/Modbus)         |
| 6) X105 – Motor connection               | 14) Shield connections for control connections |
| 7) X216 – Network (Option)               | 15) IT screw (from 0.55 kW)                    |
| 8) Switch between CANopen/Modbus         |  |

### 3 Product description

#### Overview

##### 3.2.2 i550 inverter overview




Fig. 4: i550 inverter overview

#### Position numbers

- 1) X1 – Safety module (Option)
- 2) X3 – Control terminal (standard I/O or application I/O)
- 3) X9 – Relay output
- 4) X16 – Interface for diagnostic module
- 5) X20 – Memory module
- 6) X100 – Mains connection and DC-Link connection (Only 3Ph/400V power units)
- 7) X105 – Motor and brake resistor connection
- 8) X109 – PTC input
- 9) X2xx – Network (Option)
- 10) DIP switch for baud rate and bus address (CANopen, Modbus, PROFIBUS)
- 11) Rating plate
- 12) Inverter status LEDs
- 13) Network status LEDs
- 14) Shield connection (CANopen/Modbus)
- 15) Shield connections for control connections
- 16) PE / Ground connection
- 17) IT screw (from 0.55 kW)

### 3 Product description


#### Typecode

### 3.3 Typecode

The typecode can be seen on the inverter itself and also over the parameters

#### Single parts (Only i550)

The single parts (Power unit, control unit, safety) have their own type code. These codes are also present on the complete inverter!



#### Complete inverter: (i510 & i550)

If the inverter was ordered completely an additional type code reflects the complete inverter.



1. Power unit – type code (P192:5) and serial number (P192:7)
2. Control unit – type code (P192:4) and serial number (P192:6)
3. Complete inverter – Product code (P190:1) and serial number (P190:2)

## 4 Installation

### Mechanical installation

## 4 Installation

### 4.1 Mechanical installation

#### NOTICE!

#### Possible overheating and reduced service life

Observe the minimal clearances for sufficient ventilation.



For inverter dimensions and mounting options refer to separate manual:  
i500 Mounting and switch-on instructions

### 4.2 Electrical installation

#### DANGER!

#### Dangerous electrical voltage

Possible death or severe injuries due to electrical shock.

- ▶ All installation works on the inverter must only be carried out in the deenergised state.
- ▶ After switching off the mains voltage, the capacitors in the inverter can still be charged. Observe the waiting time on the inverter label before commencing work.

#### CAUTION!

The integral solid state short circuit protection included in the inverter does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes.

#### CAUTION!

The inverter (PE) terminals connections must be connected to system earth / ground. Earth / ground impedance must conform to the requirements of national and local industrial safety regulations and all applicable electrical codes. The integrity of all earth / ground connections should be periodically checked.

## 4 Installation

### Electrical installation

#### 4.2.1 Wiring overview i510




Fig. 5: i510 wiring, 230 V AC

Connections shown by dashed lines are optional.

For 400V connection see next subchapter “4.2.2 Wiring overview i550” on page 19.



For connections to other electricity supply systems refer to separate manual:  
i500 Mounting and switch-on instructions

## 4 Installation

### Electrical installation

#### 4.2.2 Wiring overview i550




Fig. 6: i550 wiring, 400 V AC

Connections shown by dashed lines are optional.

For 230V connection see next previous subchapter "4.2.1 Wiring overview i510" on page 18



For connections to other electricity supply systems refer to separate manual:  
i500 Mounting and switch-on instructions

## 4 Installation

### Electrical installation

#### 4.2.3 Control wiring i510/i550

Terminal designation	Product			Function
	i510	i550 (Std I/O)	i550 (Appl. I/O)	
24E	—	2x *	2x *	Connection point for external 24 VDC control power
GND	2x *	3x *	5x *	Ground / earth reference for analog and digital I/O
DO1	•	•	•	Programmable digital output (24 VDC)
DO2	—	—	•	Programmable digital output (24 VDC)
AI1	•	•	•	Analog input: i510: 0...5/10 VDC, 0/4...20 mA (uni-directional) i550: -10/-5...0...5/10 VDC (bi-directional), 0/4...20 mA (uni-directional)
AI2	•	•	•	Analog input: i510: 0...5/10 VDC (uni-directional) i550: -10/-5...0...5/10 VDC (bi-directional), 0/4...20 mA (uni-directional)
10V	•	•	•	10 VDC, 10 mA supply for reference potentiometer
DI1	•	•	2x *	Programmable digital input (<5V = Low, >15V = High)
DI2	•	•	•	Programmable digital input (<5V = Low, >15V = High)
DI3	•	•	•	Programmable digital input (<5V = Low, >15V = High)
DI4	•	•	•	Programmable digital input (<5V = Low, >15V = High)
DI5	•	•	•	Programmable digital input (<5V = Low, >15V = High)
DI6	—	—	•	Programmable digital input (<5V = Low, >15V = High)
DI7	—	—	•	Programmable digital input (<5V = Low, >15V = High)
AO1	•	•	•	Programmable analog output: 0...10 VDC, 0/4...20 mA (scalable, gain, offset, deadband)
AO2	—	—	•	Programmable analog output: 0...10 VDC, 0/4...20 mA (scalable, gain, offset, deadband)
24V	•	•	•	24 VDC, 100 mA customer use and reference for DIs
COM	•	•	•	Programmable form "C" relay output: COM = Common, NC = Normally Closed, NO = Normally Open 30 VDC, 250 VAC @ 2 A
NC	•	•	•	
NO	•	•	•	
T1	—	•	•	PTC thermal sensor input 1
T2	—	•	•	PTC thermal sensor input 2
SIA	—	optional	optional	STO (safety) input A
GS	—	optional	optional	STO (safety) ground / earth reference
SIB	—	optional	optional	STO (safety) input B

\*Terminal are internally connected and can be used for loop wiring

## 4 Installation

### Electrical installation

#### 4.2.4 Default control setup

The i5x0 has a default I/O preconfiguration intended for many typical applications. This preconfiguration is described below (i510 pictured):




Fig. 7: i510, I/O preconfiguration

The i5x0 inverter can be operated “out-of-the-box” with this control scheme and without any further configuration. Below is an example of the inverter behavior based on the default signals described above:




Fig. 8: Control scheme

## 5 Commissioning

### **DANGER!**

#### Hazards during parameter change

A parameter change gets immediately active. This can result in an unexpected reaction of the motor shaft.

- ▶ Do Parameter change, if possible, only if the inverter is inhibited.

### **WARNING!**

#### Hazards during inverter installation and commissioning

Possible death or severe personal injury.

- ▶ Only authorized and qualified persons are allowed to install and commission the inverter.
- ▶ Keep the manual “i500 Mounting and switch-on instructions” at hand.
- ▶ Proper lockout/ tagout procedures must be applied to prevent inadvertently starting of motor or making alive of equipment.
- ▶ The motor shall be uncoupled from load and free to rotate before performing tests. Verify that the equipment is ready to be operated and that all safety circuits have been checked and are operational.

## 5.1 Set-up tools

Three set-up methods with special tools and software are available for commissioning the i500.

### 5.1.1 Overview

 i5MADK0000000S	<b>Keypad</b> <ul style="list-style-type: none"><li>• Change parameter</li><li>• Diagnosis</li><li>• Local control</li></ul> <p>If it's only a matter of setting a few key parameters such as acceleration and deceleration time, this can be done quickly on the keypad.</p>
 (Cable: 2.5 m EWL0085, 5m EWL0086)	<b>Easy Starter &amp; USB adapter</b> <ul style="list-style-type: none"><li>• Change parameter (advanced)</li><li>• Out of the box commissioning (parameter change without main power)</li><li>• Diagnosis</li><li>• Parameter management</li></ul> <p>If functions such as the motor potentiometer or sequence control for a positioning application need to be set, it's best to use the Easy Starter engineering tool.</p>
 i5MADW000000S	<b>WLAN &amp; Android App</b> <ul style="list-style-type: none"><li>• Change parameter (advanced)</li><li>• Diagnosis</li><li>• Parameter management</li></ul> <p>This intuitive app<ul style="list-style-type: none"><li>• Emulates the inverter keypad on a smartphone.</li><li>• Adjustment to simple applications such as a conveyor belt.</li></ul></p>

## 5 Commissioning

### Set-up tools

#### 5.1.2 Keypad

The keypad with display is snapped on the front side of the inverter.

- Keypad (Type code: i5MADK0000000S)

#### Operating elements

	Navigation in menu Adjust parameter values
	Enter (sub-)menu/parameter Confirm parameter
	Exit (sub-)menu/parameter
	Keystop inverter
	Enable inverter

Display




Fig. 9: Keypad display

Pos.	Description
1	Status and unit
2	Speed / Parameter value / Fault code
3	LOC • Local start button on keypad is active (stop button is always active)
	REM • Local start button is inactive (start is initiated remotely)
	MAN • Up/Down arrows are active and control speed
	AUTO • Up/Down arrows are inactive (speed control is external)
	Set ↵ • When blinking indicates that a setting or value has changed and needs to be entered

## 5 Commissioning

### Set-up tools

Every parameter has a hexadecimal index number. Parameters which are visible on the keypad have also a parameter number. In the Easy starter the parameter number and the hexadecimal index are visible. Every parameter can have subindex.

Example	Parameter number	Index
Base Frequency	P303.02	0x2B01:002
Control select	P200.00	0x2824:000

The parameters are organized into groups 0...7:

Group	Name	Group	Name
0	Favorites	5	Fieldbus Setup
1	Diagnostics	6	Process Controller
2	Basic Setup	7	Auxiliary Functions
3	Motor Control		
4	I/O Setup		




Group 0 - Favorites contains links to the most commonly used parameters for initial commissioning and monitoring of the inverter for general applications.

## 5 Commissioning

### Set-up tools

#### Navigation in Group 0 - Favorites



## 5 Commissioning

### Set-up tools

Fig. 10: Navigation in Group 0 - Favorites

### Navigation in Group 1-8




Fig. 11: Navigation in Group 1-7

## 5 Commissioning

### Set-up tools

---

#### 5.1.3 Easy Starter & USB adapter

##### Required materials

- USB adapter (Type code: I0MAXDU00000S)
- USB cable (standard version)  
(2.5 m EWL0085, 5m EWL0086)
- Easy Starter software (version from 1.8.0.0)
- PC or laptop with free USB port



The Easy Starter software is available for free - see download area on the Lenze web ([www.lenze.com](http://www.lenze.com)).  
Observe the system requirements and installation procedure on the download page.

##### Procedure

1. Download and install the Easy Starter software.
2. Connect USB adapter to inverter.
3. Connect USB adapter to laptop with USB cable.
  

No external voltage or mains voltage is required to program the inverter.

  
4. Run Easy Starter software.
5. Select “USB Diagnosis via adapter” for communication. Then click on “Insert” button.
6. Program inverter:

<b>Setting</b>	Guided setting windows
<b>Diagnosis</b>	Actual status of inverter / IO / Errors / Controller
<b>Parameter list</b>	Access to all parameters
<b>Trend</b>	Record data trends from inverter values



For more information see documentation of the Easy Starter software.

7. Click on the following icon to save the parameters to the inverters nonvolatile memory:



## 5 Commissioning

Commissioning procedure

### 5.2 Commissioning procedure

Use the following table as a reminder that guides you through the commissioning procedure.

Step	Action	Information
1	<b>Initial checks</b> <ul style="list-style-type: none"><li>• Check delivery for completeness.</li><li>• Check the nameplate information to ensure that you have the correct type of inverter for your motor/application.</li><li>• Check for delivery damages. Don't continue if your inverter seems to be damaged!</li></ul>	→ 3.3 Typecode, page 16
2	<b>Module assembly (only i550)</b> <ul style="list-style-type: none"><li>• Assembly your Control Unit (CU) on your Power Unit (PU) and Safety Unit (Option)</li></ul>	
3	<b>Mechanical installation</b> <ul style="list-style-type: none"><li>• Install the inverter according to the instruction.</li></ul>	
4	<b>Electrical installation</b> <ul style="list-style-type: none"><li>• If you install the inverter to an IT network, remove the IT-screws.</li><li>• Install the control wiring.</li><li>• Install motor and supply wiring in accordance to the EMC requirements.</li></ul>	→ i500 Mounting and switch-on instructions
5	<b>Functional test (if needed)</b> Perform a uncoupled functional test for basic test	
6	<b>General parameter setup</b> The i500 has linked the most common parameters to the <b>favorites menu</b> . With these parameters most common basic application can be solved.	→ 5.4 General parameter setup (Favorites) page 29
7	<b>Parameter setup (Auxiliary functions)</b> The i500 contains additional functions which can be used for more complex applications.	→ 6 Function & parameter description, page 34.
8	<b>Testrun &amp; tuning</b> <ul style="list-style-type: none"><li>• Run the motor and check the performance of your application.</li><li>• Adjust the corresponding parameter to tune your application.</li></ul>	→ 6 Function & parameter description, page 34.
9	<b>Diagnose &amp; troubleshooting</b> Status LED and error messages are available for troubleshooting.	→ 9 Troubleshooting, page 117

## 5 Commissioning

General parameter setup (Favorites)

### 5.4 General parameter setup (Favorites)

The i500 has linked the most common parameters to the favorites menu. With this parameters most common basic application can be solved.



This chapter leads you through the favorites menu and gives you basic hints.

For detailed information about the parameters and additional functions, see chapter “6 Function & parameter description” on page 34 or the separate manual: i500 Commissioning manual

#### 5.4.1 Diagnostic

P no.	Type	Name	Default setting	Unit
P100:0	Diagnostics	Actual frequency	Actual value	Hz
P103:0	Diagnostics	Actual motor current	Actual value	%
P106:0	Diagnostics	Motor voltage	Actual value	VAC
P150:0	Diagnostics	Error code	Actual value	—

Further diagnostic parameters are available in Group 1 – Diagnostics.

#### 5.4.2 Basic setup

1. Select the default control location (terminal – flexible or keypad).
2. Select the default speed set-point.
3. Select the required start and stop method for your application.
4. Check if correct mains voltage is set for your network.
5. Set the motor frequency range (see illustration below).
6. Set the motor acceleration/deceleration time (see illustration below).

P no.	Type	Name	Default setting	Unit
P200:0	Basic Setup	Control source	0: Flexible	—
P201:1	Basic Setup	Frequency setpnt.source	2: Analog input 1	—
P203:1	Basic Setup	Start method	0: Normal	—
P203:3	Basic Setup	Stop method	1: Standard Ramp	—
P208:1	Basic Setup	AC input voltage	230/400/480 Typecode dependent	VAC
P210:0	Basic Setup	Minimum frequency	0.0	Hz
P211:0	Basic Setup	Maximum frequency	50.0 / 60.0 Typecode dependent	Hz
P220:0	Basic Setup	Acceleration time 1	5.0	sec
P221:0	Basic Setup	Deceleration time 1	5.0	sec




Fig. 12: Motor settings

## 5 Commissioning

General parameter setup (Favorites)

### 5.4.3 Motor control modes

Most applications like fans, pumps, and conveyors are possible in V/f (Voltage/frequency) mode. If the application requires more dynamic and speed assurance then the SLVC (Sensor less Vector Control) mode can be used.




Fig. 13: V/F mode

For V/f mode set the following parameters:

Example: 400V/50Hz Motor  
Base Voltage = 400V  
Base Frequency = 50 Hz

P no.	Type	Name	Default setting	Unit
P300:0	Motor Control	Motor control mode	6: VFC open loop	–
P302:0	Motor Control	V/f shape	0: Linear	–
P303:1	Motor Control	Base Voltage	230/400/480 Typecode dependent	VAC
P303:2	Motor Control	Base Frequency	50.0 / 60.0 Typecode dependent	Hz



For SLVC mode refer to chapter “6.5.1 Motor control mode”, page 56.

#### Motor rotation restriction

Set this parameter if your application requires that the motor is running only in one direction:

P no.	Type	Name	Default setting	Unit
P304:0	Motor Control	Rotational restriction	1: Forwards/Reverse	–

## 5 Commissioning

General parameter setup (Favorites)

### Tuning parameters

For most applications the default tuning parameters can be used:

P no.	Type	Name	Default setting	Unit
P305:0	Motor control	Switching frequency	21: 8kHz var/opt/4kHz min.	kHz
P308:1	Motor control	Load at 60 sec	150	%
P316:1	Motor control	V/f boost: static	0.4%...2.5% Typecode dependent	%
P324:0	Motor control	Max current	200.0	%



If the performance is insufficient during operation, see chapter “Motor Control setup” for tuning the parameters above.

### Control selection

The i500 can be controlled from various locations and in different ways.

P no.	Type	Name	Default setting	Unit
P200:0	Basic Setup	Control source	0: Flexible	–

#### Basic functionalities:

- **Inverter enable**  
Enables the inverter. Signal must have the state TRUE (by Input or setting) to be able to start the motor.
- **Run/Stop**  
Enables the running of the motor. Can be used as single signal or in combination with the signals Start Forward / Start Reverse. Signal must have the state TRUE (by Input or setting) to be able to start the motor.
- **Start Forward / Start Reverse**  
Used to start the motor (Positive edge triggered). Stop is down with the **Run/Stop** signal.
- **Run Forward / Run Reverse**  
Used to run and stop the motor (Maintained signals)
- **Rotation inversion**  
Inverts the speed setpoint
- **Fault Reset**  
For a successful reset of a fault it is necessary to correct the condition that caused the fault first. Afterwards there are different possibilities to reset the fault:
- **Quick Stop (QSP)** works as “pause” / “zero-speed” function. (The QSP ramp time can be set in P225:0)



In **Flexible Control mode** (P200:0) either **Inverter enable (P400:1)** or **Run/Stop (P400:2)** must be assigned to I/O to ensure that the drive can always be stopped!  
(Exception: Inverter is controlled from network, **Network enable (P400:37)** is HIGH)



See chapter “6.2.3 Control examples” on page 39 for control application examples.

See chapter “6.6.1 Function list (Run/Stop/Start/Jog/Reverse)” on page 69 for detailed information

P no.	Type	Name	Default setting	Unit
P400:1	I/O Setup	Inverter enable	1: TRUE	–
P400:2	I/O Setup	Run/Stop	11: Digital input 1	–
P400:3	I/O Setup	Quick Stop [QSP]	0: Not connected	–

## 5 Commissioning

General parameter setup (Favorites)

P400:4	I/O Setup	Reset fault	12: Digital input 2	-
P400:5	I/O Setup	DC brake	0: Not connected	-
P400:6	I/O Setup	Start forward (CW)	0: Not connected	-
P400:7	I/O Setup	Start reverse (CCW)	0: Not connected	-
P400:8	I/O Setup	Run forward (CW)	0: Not connected	-
P400:9	I/O Setup	Run reverse (CCW)	0: Not connected	-
P400:13	I/O Setup	Invert rotation	13: Digital input 3	-
P no.	Type	Name	Default setting	Unit
P400:18	I/O Setup	Preset selection bit0	14: Digital input 4	-
P400:19	I/O Setup	Preset selection bit1	15: Digital input 5	-
P400:20	I/O Setup	Preset selection bit2	0: Not connected	-

### Output selection

The digital output and relay can be used as feedback signal for your control system.

P no.	Type	Name	Default setting	Unit
P420:1	I/O Setup	Relay function	51: Ready to run	-
P420:2	I/O Setup	DO1 function	115: Holding brake	-

### Analog input 1 for speed setpoint




Fig. 14: Speed setpoint

If you have defined the AI1 as your speed setpoint define the correct input scaling.

P no.	Type	Name	Default setting	Unit
P430:1	I/O Setup	AI1 configuration	0: ...10VDC	-
P430:2	I/O Setup	AI1 frequency @ min	0.0	Hz
P430:3	I/O Setup	AI1 frequency @ max	50.0/60.0 *Typecode dependent	Hz

## 5 Commissioning

### General parameter setup (Favorites)

---

#### Analog output 1

Analog output can be used as a feedback for your control system. Select the correct scaling and range (See Fig. 14 for Scaling):

P no.	Type	Name	Default setting	Unit
P440:1	I/O Setup	AO1 configuration	1: 0...10VDC	–
P440:2	I/O Setup	AO1 function	1: Output freq.	–
P440:3	I/O Setup	AO1 function @ min	0	–
P440:4	I/O Setup	AO1 function @ max	1000	–

#### Preset frequency

Define your basic preset frequency if required:

P no.	Type	Name	Default setting	Unit
P450:1	I/O Setup	Preset 01	20.0	Hz
P450:2	I/O Setup	Preset 02	40.0	Hz
P450:3	I/O Setup	Preset 03	50.0/60.0 *Typecode dependent	Hz
P450:4	I/O Setup	Preset 04	0.0	Hz


## 6 Function & parameter description

Parameter / function overview

# 6 Function & parameter description

## 6.1 Parameter / function overview

The i500 series is a multipurpose inverter with a various amount of functionalities. For fast and easy commissioning the parameters are grouped. The group 0 “Favorites” contains a link to the most common used parameters. The following graphic shows an overview over the functionalities and where they can be programmed. For detailed information see the corresponding chapter.



## 6 Function & parameter description

### Parameter / function overview

Every parameter has a hexadecimal index number. Parameters which are visible on the keypad have also a parameter number. In the Easy starter the parameter number and the hexadecimal index are visible. Every parameter can have subindex.

Example	Parameter number	Index
Base Frequency	P303.02	0x2B01:002
Control select	P200.00	0x2824:000

P510:1	0x23A1:1	IP address (*)	I550	R/V
-- ... [192.168.124.16] ... --	EtherNet/IP address settings			

Parameters which are not visible on the keypad are marked in the manual as P (Without number)

Parameters or selections with marking (\*) are not available on all control unit types.

Example:

P510:1	0x23A1:1	IP address (*)	I550
-- ... [192.168.124.16] ... --	EtherNet/IP address settings		

## 6 Function & parameter description

### Control concept

## 6.2 Control concept

### 6.2.1 Setpoint structure / operation mode

The i500 can be used for various applications. The graphic below gives an overview for the operation modes and the setpoint structure.

#### Modes of Operation

In general the inverter has 2 modes of operation:

- Lenze velocity mode (PID optionally)
- Velocity mode (CiA402)

#### Setpoint source

First of all the setpoint depends on the selected operation mode (P301:0). Every mode has a default setpoint source (P201:1, P201:2, P201:3). This default setpoint source applies if no other source is selected. In the connection list (P400:15 to 400:21). On the list below the priority of the different source signals can be seen.

→ See chapter “6.4.2 Default setpoint”, on page 50  
See chapter “6.6.2 Setpoint selection”, on page 73

**i** The actual control setpoint source can be seen in P125:2

#### Setpoint Priority:


The priority of the setpoint is according the following list:

Flexible or Keypad control (P400:37 Network Enable= False)	Network mode (P400:37 Network Enable= TRUE)
<ol style="list-style-type: none"><li>1. <b>Trigger for Setpoint Source (Connection List)</b> <b>P400:14 – P400:25</b> In order of the selected trigger 1. 1: Constant TRUE 2. 11: Digital Input 1 3. 12: Digital Input 2 4. 13: Digital Input 3</li><li>2. <b>Default setpoint source</b> <b>Frequency P201:1 (0x2860:1)</b> <b>PID P201:2 (0x2860:2)</b></li></ol>	<ol style="list-style-type: none"><li>1. <b>Setpoint/Network setpoint controlled with:</b> AC Drive Control Word C135 Control Word NETWordIN1</li><li>2. <b>Default setpoint source</b> <b>Frequency P201:1 (0x2860:1)</b> <b>PID P201:2 (0x2860:2)</b></li></ol>

**i** In Network mode (P400:37 = TRUE) the triggers P400:14 – P400:25 are not active.  
To select the network as setpoint source in network mode (P400:37 = TRUE) use the “Default setpoint source” (P201:1-2) or the corresponding control bits (AC Drive Control Word, C135 Control Word, NETWordIN1).

## 6 Function & parameter description

### Control concept






## 6 Function & parameter description

### Control concept





#### 6.2.2 Control Source

The i500 can be controlled from various locations like digital IO's, keypad or network. The following graphic gives an overview of the parameters and their influence.

##### I) Inverter Enable / Run/Stop / Quick Stop



##### II) Start / Stop / JOG



**Active control source (STATUS)**  
**P125:1 (0x282B:1)**  
0: Flexible  
1: Network  
2: Keypad

**Motor Control**  
**Start method**  
P203:1 (0x2838:1)  
**Stop method**  
P203:3 (0x2838:3)

**Network enable**  
**P400:37 (0x2631:37)**  
0 = FALSE (Connection List Active)  
1 = TRUE (Network Active)  
... Other options / external triggers

**Keypad control**  
**P400:12 (0x2631:12)**  
0 = FALSE (Normal Drive Operation)  
1 = TRUE (Keypad Active)  
... Other options / external triggers

**Control source**  
**P200:0 (0x2824:0)**  
0 = Flexible  
1 = Keypad ONLY



The actual control source can be seen in P125:1

## 6 Function & parameter description

### Control concept


#### 6.2.3 Control examples

The inverter can be configured with different Run/Start/Stop signals. The following 3 examples show the most commonly used signals with the corresponding parameters and a signal flow chart which explains in detail the behavior of the inverter.

##### Run/Stop (One Signal)

- Using one signal **Run/Stop** to start and stop the inverter. **Run/Stop** Level High will start the inverter, Level Low will stop the inverter according to the selected stop method (P203:3)
- **Invert Rotation** Level High will change the motor direction

Parameter	Parameter Name	Default LENZE Setting
P400:1	Inverter enable	1: Constant TRUE
P400:2	Run/Stop	11: Digital input 1
P400:3	Quick stop	0: Not connected
P400:6	Start forward (CW)	0: Not connected
P400:7	Start reverse (CCW)	0: Not connected
P400:8	Run forward (CW)	0: Not connected
P400:9	Run reverse (CCW)	0: Not connected
P400:13	Invert rotation	13: Digital input 3




## 6 Function & parameter description

### Control concept

#### Start forward/reverse (Rising Edge triggered Signals)

- Start using flag triggered signals **Start forward (CW)** and **Start reverse (CCW)**
- Run/Stop** Level LOW will stop the inverter according to the selected stop method (P203:3)

Parameter	Parameter Name	Setting for this example
P400:1	Inverter enable	1: Constant TRUE
P400:2	Run/Stop	11: Digital input 1
P400:3	Quick stop	0: Not connected
P400:6	Start forward (CW)	12: Digital input 2
P400:7	Start reverse (CCW)	13: Digital input 3
P400:8	Run forward (CW)	0: Not connected
P400:9	Run reverse (CCW)	0: Not connected
P400:13	Invert rotation	0: Not connected




## 6 Function & parameter description

### Control concept

#### Run Forward/Reverse (Steady Signals)

- Start using steady signals **Run Forward (CW)** and **Run Reverse (CCW)**. If no Run command is active the motor will stop according the selected stop method (P203:3)
- Inverter enable** Level Low will stop the inverter with a coast stop.

Parameter	Parameter Name	Setting for this example
P400:1	Inverter enable	11: Digital input 1
P400:2	Run/Stop	1: Constant TRUE
P400:3	Quick stop	0: Not connected
P400:6	Start forward (CW)	0: Not connected
P400:7	Start reverse (CCW)	0: Not connected
P400:8	Run forward (CW)	12: Digital input 2
P400:9	Run reverse (CCW)	13: Digital input 3
P400:13	Invert rotation	0: Not connected



## 6 Function & parameter description

### Control concept

#### 6.2.4 Rotation direction

The rotation of the motor depends on different parameters.

- **Commands Forward/Reverse**

The reverse commands invert the setpoint (Multiplied by factor -1).

Exception: If the input is bidirectional (-10V ... +10V), the direction Forward/Reverse of the Start and Run are ignored


- **Invert rotation**

The function "Invert rotation" inverts the speed setpoint (Multiplied by factor -1)

- **Rotation restriction**

The rotation can be restricted to forward. Negative set points will be ignored.

The following graphic shows an overview of the rotation direction:



Note:

\* If the input is bidirectional (-10V..10V), the direction FWD/REV of the Start and Run are ignored

\*\* Only positive value can be entered

\*\*\*Direction changes only if speedsetpoint is higher than fmin!

## 6 Function & parameter description

### Group 1 – Diagnostics

## 6.3 Group 1 – Diagnostics

### General:

Bit coded status words are displayed on the keypad as described in the following picture:




Fig. 15: Display of bit coded status word on keypad

### 6.3.1 General Diagnostic Data

<b>P100:0</b>	<b>0x2DDD:0</b>	<b>Actual frequency</b>	i510	i550	R
-- ... [Actual value] ... -- Hz	Actual motor frequency				
<b>P101:0</b>	<b>0x400D:0</b>	<b>Scaled actual value</b>	i510	i550	R
-- ... [Actual value] ... -- Units	Actual motor speed in user units. Actual frequency x Scaling factor (P702:0)				
<b>P102:0</b>	<b>0x2B0E:0</b>	<b>Frequency setpoint</b>	i510	i550	R
-- ... [Actual value] ... -- Hz	Actual frequency setpoint				
<b>P103:0</b>	<b>0x6078:0</b>	<b>Actual motor current</b>	i510	i550	R
-- ... [Actual value] ... -- %	Actual motor current in % of P323:0				
<b>P104:0</b>	<b>0x2D88:0</b>	<b>Actual motor current</b>	i510	i550	R
-- ... [Actual value] ... -- A	Actual motor current				
<b>P105:0</b>	<b>0x2D87:0</b>	<b>DC-bus voltage</b>	i510	i550	R
-- ... [Actual value] ... -- V	Actual DC-Link voltage				
<b>P106:0</b>	<b>0x2D89:0</b>	<b>Actual motor voltage</b>	i510	i550	R
-- ... [Actual value] ... -- VAC	Actual motor voltage				
<b>P107:0</b>	<b>0x6077:0</b>	<b>Actual torque</b>	i510	i550	R
-- ... [Actual value] ... -- %	Actual motor torque (100% = Max. torque)				

## 6 Function & parameter description

Group 1 – Diagnostics

### 6.3.2 Output Power

<b>P108:1</b>	<b>0x2DA2:1</b>	<b>Effective power</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- kW		Actual motor effective power			
<b>P108:2</b>	<b>0x2DA2:2</b>	<b>Apparent power</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- kVA		Actual motor apparent power			

### 6.3.3 Output Energy

<b>P109:1</b>	<b>0x2DA3:1</b>	<b>Motor</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- kWh		Estimated energy at the inverter output when the motor is being driven.			
<b>P109:2</b>	<b>0x2DA3:2</b>	<b>Generator</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- kWh		Estimated energy at the inverter output when the motor is regenerating.			

### 6.3.4 Analog Input 1 Diagnosis

<b>P110:1</b>	<b>0x2DA4:1</b>	<b>Percent value</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- %		Actual value of AI1 in % of the selected input range			
<b>P110:2</b>	<b>0x2DA4:2</b>	<b>Frequency value</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- Hz		Actual value of AI1 as frequency setpoint			
<b>P110:3</b>	<b>0x2DA4:3</b>	<b>Process controller value</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- PUnit		Actual value of AI1 as PID input			
<b>P110:4</b>	<b>0x2DA4:4</b>	<b>Torque value</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- %		Actual value of AI1 as torque setpoint			
<b>P110:16</b>	<b>0x2DA4:16</b>	<b>Status analog input 1</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Bit coded status of AI1			

### 6.3.5 Analog Input 2 Diagnosis

<b>P111:1</b>	<b>0x2DA5:1</b>	<b>Percent value</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- %		Actual value of AI2 in % of the selected input range			
<b>P111:2</b>	<b>0x2DA5:2</b>	<b>Frequency value</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- Hz		Actual value of AI2 as frequency setpoint			
<b>P111:3</b>	<b>0x2DA5:3</b>	<b>Process controller value</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- PUnit		Actual value of AI2 as PID input			
<b>P111:4</b>	<b>0x2DA5:4</b>	<b>Torque value</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- %		Actual value of AI2 as torque setpoint			
<b>P111:16</b>	<b>0x2DA5:16</b>	<b>Status analog input 2</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Bit coded status of AI2			

### 6.3.6 Analog Output 1 Value

<b>P112:1</b>	<b>0x2DAA:1</b>	<b>Voltage</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- V		Actual output voltage of A01			
<b>P112:2</b>	<b>0x2DAA:2</b>	<b>Current</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- mA		Actual output current of A01			

## 6 Function & parameter description

Group 1 – Diagnostics

### 6.3.7 Analog Output 2 Value

<b>P113:1</b>	<b>0x2DAB:1</b>	<b>Voltage (*)</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- V	Actual output voltage of A02			
<b>P113:2</b>	<b>0x2DAB:2</b>	<b>Current (*)</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- mA	Actual output current of A02			

### 6.3.8 Heatsink temperature

<b>P117:1</b>	<b>0x2D84:1</b>	<b>Heatsink temperature</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- °C	Actual heatsink temperature				

### 6.3.9 I/O Status

<b>P118:0</b>	<b>0x60FD:0</b>	<b>Digital inputs status</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
Bit # description: 16: Level at digital input 1 17: Level at digital input 2 18: Level at digital input 3 19: Level at digital input 4 20: Level at digital input 5 21: Level at digital input 6 22: Level at digital input 7 25: Low active - NPN		Status of digital input (Bit coded) Display toggles between LWX/HWX LWX Bit 0-15 HGX Bit 16 - 31			
<b>P119:0</b>	<b>0x2DAC:0</b>	<b>Keypad status</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
Bit # description: 0: Start Key 1: Stop Key 2: Up Key 3: Down Key 4: Enter Key 5: Escape Key		Keypad status (Bit coded)			
<b>P120:0</b>	<b>0x2DAD:0</b>	<b>Digital outputs status</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
Bit # description: 0: Relay 1: Digital output 1 2: Digital output 2 10: Charge Relay		Status of digital outputs and relay (Bit coded)			

### 6.3.10 Process Controller Diagnosis

<b>P121:1</b>	<b>0x401F:1</b>	<b>PID setpoint</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- PUnit	Actual PID setpoint				
<b>P121:2</b>	<b>0x401F:2</b>	<b>PID feedback</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- PUnit	Actual PID feedback				
<b>P121:3</b>	<b>0x401F:3</b>	<b>Status (PID)</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
Bit # description: 0: Process controller off 1: PID output set to 0 2: PID I-component set to 0		PID status (Bit coded)			

## 6 Function & parameter description

Group 1 – Diagnostics

3: PID influence shown 4: Setpoint = actual value 5: Sleepmode active	
---	--

### 6.3.11 Motor protection i2xt

<b>P123:0</b>	<b>0x2D4F:0</b>	<b>Motor utilisation (<math>i^2*t</math>)</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Actual thermal load of the motor (i2xt)			

### 6.3.12 Control / Setpoint Source

<b>P125:1</b>	<b>0x282B:1</b>	<b>Active control source</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Actual active control source			
<b>P125:2</b>	<b>0x282B:2</b>	<b>Active setpoint source</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Actual active setpoint source			
<b>P125:3</b>	<b>0x282B:3</b>	<b>LCD icon states</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Actual status of LCD (Bit coded)			
<b>P125:4</b>	<b>0x282B:4</b>	<b>Active drive mode</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Actual drive mode			
<b>P125:5</b>	<b>0x282B:5</b>	<b>Actual control register</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Network Mode: Last active control register. Parameter Index is shown as hex code: Format: Oxiiiiss00 (iii = Index hexadezimal, ss = Subindex hexadezimal) Example: 0x400C0100 --> 0x400C:01			
<b>P125:6</b>	<b>0x282B:6</b>	<b>Actual setpoint register</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Network Mode: Last active setpoint register. Parameter Index is shown as hex code: Format: Oxiiiiss00 (iii = Index hexadezimal, ss = Subindex hexadezimal) Example: 0x400B0300 --> 0x400B:03			

### 6.3.13 Inverter status

<b>P126:1</b>	<b>0x282A:1</b>	<b>Cause of disable</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
Bit # description: 0: Flexible I/O: Inhibit 1: Network inhibit 2: Axis inhibit 6: DC bus voltage 7: Drive not ready 9: Motor parameter ident 10: Auto brake 12: CiA 402 disabled 13: CIA402 Quick stop inhibit 14: STO inhibit 15: CiA402 mode disabled		Cause of controller stop (Bit coded)			
<b>P126:2</b>	<b>0x282A:2</b>	<b>Cause of quick stop</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
Bit # description: 0: Flexible I/O: configuration 1: Network 2: Axis command		Cause of quick stop (Bit coded)			

## 6 Function & parameter description

### Group 1 – Diagnostics

<b>P126:3</b>	<b>0x282A:3</b>	<b>Cause of stop</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
Bit # description: 0: Flexible I/O: Run/Stop 1: Flexible I/O: Run CW 2: Flexible I/O: Run CCW 3: Flexible I/O: Jog CW 4: Flexible I/O: Jog CCW 5: Network 6: Keypad 7: Control mode transition 15: Waiting for start		Cause of stop (Bit coded)			
<b>P126:5</b>	<b>0x282A:5</b>	<b>CiA402 state machine</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
0: Initial 2: Not Ready to Switch On 3: Switch On Disabled 4: Ready to Switch On 5: Switched on 6: Operation enable 7: Disable Operation 8: Shut Down 9: Quick stop active 10: Fault reaction active 11: Fault		Actual state of inverter			

### 6.3.14 Device utilization (ixt)

<b>P135:4</b>	<b>0x2D40:4</b>	<b>Device utilisation (i*t)</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- %		Actual inverter utilization			
<b>P135:5</b>	<b>0x2D40:5</b>	<b>Device utilisation (i*t): Error response</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
2: Trouble 3: Error		Configuration of ixt error response			

### 6.3.15 Error code

<b>P150:0</b>	<b>0x603F:0</b>	<b>Error code</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Actual pending error code. See chapter "Troubleshooting" for code explanation			

### 6.3.16 Timer / Counter

On the keypad timers are displayed in the following format:

Days (d), Hours (h), Minutes (m), Seconds (s)      (Example: 05d15h13m12s)

<b>P151:1</b>	<b>0x2D81:1</b>	<b>Operating time</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- s		Total operating time of inverter (Inverter released)			
<b>P151:2</b>	<b>0x2D81:2</b>	<b>Power-on time</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- s		Total time that inverter was powered on			
<b>P151:3</b>	<b>0x2D81:3</b>	<b>Control unit operating time</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- ns		Total time that control unit was powered on. It includes the time where the control section is powered by USB adapter.			

## 6 Function & parameter description

### Group 1 – Diagnostics

<b>P151:4</b>	<b>0x2D81:4</b>	<b>Main Switching Cycles</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Total number of power cycles			
<b>P151:5</b>	<b>0x2D81:5</b>	<b>Relay switching cycles</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Total number of relay switchings			
<b>P151:6</b>	<b>0x2D81:6</b>	<b>Short-circuit counter</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Total number of short circuit detections			
<b>P151:7</b>	<b>0x2D81:7</b>	<b>Earth fault counter</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Total number of earth faults			
<b>P151:8</b>	<b>0x2D81:8</b>	<b>Clamp counter</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Total number of active clamping			
<b>P151:9</b>	<b>0x2D81:9</b>	<b>Fan operating time</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... -- s		Total time of running fan.			

### 6.3.17 History Buffer

<b>P155:0</b>	<b>0x2006:0</b>	<b>Error history buffer</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		See chapter "Troubleshooting"			

### 6.3.18 Device data

<b>P190:1</b>	<b>0x2000:1</b>	<b>Product code</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Product code of complete inverter Example: I55AE222D10V10017S (If control unit and power unit were ordered separately it will indicate XXXXXXXXXXXXXXXXXXXX)			
<b>P190:2</b>	<b>0x2000:2</b>	<b>Serial number</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Serial number of complete inverter Example: 000000000000000XYZXYZ (If control unit and power unit were ordered separately it will indicate XXXXXXXXXXXXXXXXXXXX)			
<b>P190:4</b>	<b>0x2000:4</b>	<b>Ctrl unit firmware version</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Example: 01.00.01.00			
<b>P190:5</b>	<b>0x2000:5</b>	<b>Control unit - firmware type</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Example: IOFW51AC10			
<b>P190:6</b>	<b>0x2000:6</b>	<b>Ctrl unit bootloader version</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Example: 00.00.00.13			
<b>P190:7</b>	<b>0x2000:7</b>	<b>Control unit- bootloader type</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Example: IOBL51AOnn			
<b>P190:8</b>	<b>0x2000:8</b>	<b>Object directory version</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Example: 108478			
<b>P190:10</b>	<b>0x2000:10</b>	<b>Power unit- firmware version</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Example: 00196			
<b>P190:11</b>	<b>0x2000:11</b>	<b>Power unit - firmware type</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Example: IDF55AA			
<b>P190:12</b>	<b>0x2000:12</b>	<b>Power Unit bootloader vers.</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --					

## 6 Function & parameter description

Group 2 – Basic setup

<b>P190:13</b>	<b>0x2000:13</b>	<b>Power unit - bootloader type</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --					

### 6.3.19 Device Name

<b>P191:0</b>	<b>0x2001:0</b>	<b>Device name</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
-- ... [My Device] ... --		Configurable name of inverter			

### 6.3.20 Device Module

<b>P192:4</b>	<b>0x2002:4</b>	<b>Control unit - type code</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Type code of control unit Example: I5CA500200V000000S		
<b>P192:5</b>	<b>0x2002:5</b>	<b>Power unit - product code</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --		Type code of power unit Example: I5DAE222F10V1000S		
<b>P192:6</b>	<b>0x2002:6</b>	<b>Control unit - serial number</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --				
<b>P192:7</b>	<b>0x2002:7</b>	<b>Power unit - serial number</b>	<b>i550</b>	<b>R</b>
-- ... [Actual value] ... --				

### 6.3.21 Additional status

<b>P197:0</b>	<b>0x2040:0</b>	<b>Access protection status</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
Bit # description: 0: Full write access protected 1: Write access only for favorites		Actual status of access protection 0 = No protection 1 = Only read access to all parameters 2 = Only read & write access on favorites group			
<b>P198:0</b>	<b>0x2827:0</b>	<b>Loaded parameter status</b>	<b>i510</b>	<b>i550</b>	<b>R</b>
0: User settings 1: Reset 60 Hz Settings 2: Reset 50 Hz Settings 3: OEM Settings		Actual loaded parameter settings			

## 6.4 Group 2 – Basic setup

### 6.4.1 Default control source



See chapter “6.2.1 Setpoint structure / operation mode”, page 36

See chapter “6.2.2 Control Source”, page 38

<b>P200:0</b>	<b>0x2824:0</b>	<b>Control source</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0: Flexible</b>		Defines the default Control Source for Start, Stop and Rotation direction. The inverter can be controlled from several sources such as terminals (Digital Inputs), Fieldbus or Keypad.			
<b>1: Keypad</b>		<b>O: Flexible Control</b> Start / Stop and rotation direction configured in P400.xx			

## 6 Function & parameter description

### Group 2 – Basic setup

	<p><b>1: Keypad</b> Local or remote mounted keypad provides the start / stop commands to the inverter. Other sources for starting the inverter are ignored in this mode.</p> <p><b>NOTE:</b> Digital Input "Inverter Enable" (P400:1), "Run/Stop" (P400:2) and Keypad Stop are always active!</p>
--	---

#### 6.4.2 Default setpoint

The default setpoint selects the setpoint sources that will become active when no other setpoint is selected by any other means. The default setpoint values can come from external sources (Analog Inputs, Network, etc.) and internal sources (Presets)

→ See chapter 6.2.1 Setpoint structure / operation mode, page 36

P201:1	0x2860:1	Frequency control: Default setpoint source	i510	i550	R/W
1: Keypad frequency setpoint		Default Frequency setpoint			
<b>2: Analog input 1</b>		<b>1: Keypad frequency setpoint</b> Setpoint by Up and Down buttons on the optional local or remote keypad			
3: Analog input 2		<b>2: Analog input 1</b> Selects analog input 1 as default setpoint.			
5: Network frequency setpoint		<b>3: Analog input 2</b> Selects analog input 2 as default setpoint.			
11: Preset frequency val. 1		<b>5: Network frequency setpoint</b> Selects the network as default setpoint			
12: Preset frequency val. 2		<b>Frequency: 11..25: Preset val. 1..15</b> Selects the preset values defined in P450:1 - P450:15 as default setpoint			
13: Preset frequency val. 3		<b>PID: 11..18: Preset setpoint 1..18</b> Selects the preset values defined in P451:1 - P451:8 as default setpoint			
14: Preset frequency val. 4		<b>Torque: 11..18: Preset setpoint 1..18</b> Selects the preset values defined in P452:1 - P452:8 as default setpoint			
15: Preset frequency val. 5		<b>31-38: Preset segment</b> Select sequencer segment setting as default setpoint			
16: Preset frequency val. 6		<b>50: Motor potentiometer (MOP)</b> Default setpoint defined by MOP (Motorized potentiometer function). Two digital inputs (increase/decrease) control the setpoint			
17: Preset frequency val. 7					
18: Preset frequency val. 8					
19: Preset frequency val. 9					
20: Preset frequency val. 10					
21: Preset frequency val. 11					
22: Preset frequency val. 12					
23: Preset frequency val. 13					
24: Preset frequency val. 14					
25: Preset frequency val. 15					
50: Motor potentiometer (MOP)					
P201:2	0x2860:2	PID control : Default setpoint source	i510	i550	R/W
<b>1: Keypad PID setpoint</b> (Reference see P201:1)		Default PID setpoint			

## 6 Function & parameter description

Group 2 – Basic setup

### 6.4.3 Keypad setpoints

<b>P202:1</b>	<b>0x2601:1</b>	<b>Frequency setpoint</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
0.0 ... [20.0] ... 599.0 Hz	Actual Keypad setpoint, defined by Up and Down buttons				
<b>P202:2</b>	<b>0x2601:2</b>	<b>Process controller setpoint</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
-300.00 ... [0.00] ... 300.00 PUnit	Actual Keypad PID setpoint, defined by Up and Down buttons				

### 6.4.4 Start and Stop configuration

The motor can be started and stopped with different methods:




Fig. 16: Start and Stop configuration



See chapter “6.9.3DC brake setup”, page 88 for DC brake setup

<b>P203:1</b>	<b>0x2838:1</b>	<b>Start method</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0: Normal</b>	Defines starting method of the motor				
1: Start with DC brake	<b>0: Normal:</b> Inverter accelerates the motor in the selected direction when the start is initiated				
2: Flying Start	<b>1: Start with DC brake:</b> Inverter apply the DC Brake when the start is initiated, before beginning rotation of the motor. When the DC Brake delay time has elapsed the				


## 6 Function & parameter description

### Group 2 – Basic setup

		acceleration of the motor will begin. To activate DC Brake also P704:1 and P704:2 need to be set.	
P203:3	0x2838:3	<p><b>2: Flying Start:</b> Inverter can start on a rotating motor. During start the inverter detects the actual frequency and catches the motor. This feature provides smoother starting for high inertia loads like fans, flywheels, etc...</p> <p><b>Stop method</b></p> <p>Defines the Stopping method of the motor</p> <p><b>0: Coast</b> Inverter will shut off the output of the motor and the motor will coast to stop based on the inertia of the machine.</p> <p><b>1: Standard Ramp</b> Inverter will ramp down the motor according to the selected deceleration time</p> <p><b>2: Quick stop ramp</b> Inverter will ramp down the motor according to the quick stop ramp.</p>	i510 i550 R/W

#### 6.4.5 Start on power up

The “Start on Power” function allows to start the inverter automatically upon application of mains power if a valid start signal is present.



P203:2	0x2838:2	Start on Power up	i510	i550	R/W
<b>0: Off</b> 1: On		<p>Configuration of “Start on Power” function</p> <p><b>0: Off</b> Already present start/run signal upon application of mains power are ignored. The inverter needs a new start/run signal to start.</p>			

## 6 Function & parameter description

### Group 2 – Basic setup

	<b>1: On</b> The inverter starts automatically when mains power is applied and a valid start/run command is present.
--	---

#### 6.4.6 Voltage configuration

P208:1	0x2540:1	Rated mains voltage	i510	i550	R/W
0: 230 Veff 1: 400 Veff 2: 480 Veff 10: 230V:reduced LU level (*)		Configuration of the actual applied mains voltage (VAC).  Note: Default value is type code dependent			
P208:2	0x2540:2	Warninglevel under voltage	i510	i550	R/W
0 ... [Type Code dependent] ... 800 V		Warning threshold for undervoltage If the DC-bus voltage falls below the threshold value the inverter reports a warning. Reset of the warning is done with a hysteresis of 10V.			
P208:3	0x2540:3	Error level under voltage	i510	i550	R
-- ... [Actual value] ... -- V		Error threshold for undervoltage If the DC-bus voltage falls below the threshold value the inverter changes to Error state.			
P208:4	0x2540:4	Clear level under voltage	i510	i550	R
-- ... [Actual value] ... -- V		Error reset threshold for undervoltage			
P208:5	0x2540:5	Warning level over voltage	i510	i550	R/W
0 ... [Type Code dependent] ... 800 V		Warning threshold for overvoltage If the DC-bus voltage exceeds the threshold value the inverter reports a warning. Reset of the warning is done with a hysteresis of 10V.			
P208:6	0x2540:6	Error level over voltage	i510	i550	R
-- ... [Actual value] ... -- V		Error threshold for overvoltage If the DC-bus voltage exceeds the threshold value the inverter changes to Error state.			
P208:7	0x2540:7	Clear level over voltage	i510	i550	R
-- ... [Actual value] ... -- V		Error reset threshold for overvoltage			

#### 6.4.7 Min/Max frequency

Minimum Frequency and Maximum Frequency define the overall operating frequency range (Hz) of the inverter. All references setpoints (analog input frequency setpoints, preset frequency setpoints, network frequency setpoints, etc...) are limited this settings.

P210:0	0x2915:0	Minimum frequency	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Minimum motor frequency			
P211:0	0x2916:0	Maximum frequency	i510	i550	R/W
0.0 ... [Type Code dependent] ... 599.0 Hz		Maximum motor frequency			

## 6 Function & parameter description

### Group 2 – Basic setup

#### 6.4.8 Acceleration / Deceleration

Two sets of Acceleration/Deceleration ramps are available. Two ways of switching between ACC/DEC 1 and ACC/DEC 2 are available:

- External Trigger (i.e. Digital Input)
- Ramp time switch level to trigger from ACC/DEC1 tp ACC/DEC2 based on Frequency




Fig. 17: Speed setpoint

P400:39	0x2631:39	Ramp 2 selection	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		Trigger for ACC/DEC2 selection:  TRUE: Selects ACC2/DEC2 as ramp times			
<b>P220:0</b>	<b>0x2917:0</b>	<b>Acceleration time 1</b>	i510	i550	R/W
0.0 ... [5.0] ... 3600.0 s		Acceleration time 1 for the output frequency to increase from 0.0 Hz to Maximum frequency (P211:0)			
<b>P221:0</b>	<b>0x2918:0</b>	<b>Deceleration time 1</b>	i510	i550	R/W
0.0 ... [5.0] ... 3600.0 s		Deceleration time 1 for the output frequency to decrease from P211:0 Maximum Frequency to 0.0 Hz			
<b>P222:0</b>	<b>0x2919:0</b>	<b>Acceleration time 2</b>	i510	i550	R/W
0.0 ... [5.0] ... 3600.0 s		Acceleration time 2 for the output frequency to increase from 0.0 Hz to Maximum frequency (P211:0)  Note: MOP use ACC/DEC2			
<b>P223:0</b>	<b>0x291A:0</b>	<b>Deceleration time 2</b>	i510	i550	R/W
0.0 ... [5.0] ... 3600.0 s		Deceleration time 2 for the output frequency to decrease from Maximum Frequency (P211:0) to 0.0 Hz  Note: MOP use ACC/DEC2			

## 6 Function & parameter description

Group 2 – Basic setup

P224:0	0x291B:0	Ramp time switch level	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Switch point between ACC/DEC1 and ACC/DEC2: Act frequency < Ramp time switch level (P224:0) --> Use Accel/Decel time #1 Act frequency > Ramp time switch level(P224:0) --> Use Accel/Decel time #2  0: Function Disabled  <b>Note:</b> Selection of ACC/DEC by P400:39, PID ACC/DEC sequencer ACC/DEC, Quickstops have higher priority			
P226:1	0x291E:1	Smooth factor	i510	i550	R/W
0.0 ... [0.0] ... 100.0 %		Smoothing factor for S-Shap characteristic ramping. <b>Note:</b> Smoothing factor will extend ramp time: 50% --> 1,5 x configured ramp time 100% --> 2 x configured ramp time			

### 6.4.9 Quickstop ramp time (QSP)

The inverter has an additional stopping method called “Quick Stop” (QSP) It works as a zero-speed or Pause function where the ramp time can be setup separately.

P225:0	0x291C:0	Quick stop decel. time	i510	i550	R/W
0.0 ... [1.0] ... 3600.0 s		Quick stop ramp time for the output frequency to decrease from Maximum frequency (P211:0) to 0.0 Hz  <b>Note:</b> In Cia402 Velocity mode (P301:0 = [2] Velocity mode (vl) ) the quick stop deceleration time is defined by P790:0.			

## 6 Function & parameter description

### Group 3 – Motor control

## 6.5 Group 3 – Motor control

### 6.5.1 Motor control mode

The inverter can control the motor in different modes:

AC induction motors:

Motor control mode (P300:0)	Modes of operation (P301:0)	V/f characteristic shape (P302:0)	i510	i550
VFC open loop [6]	MS-Velocity mode [-2]	Linear [0]	X	X
		Quadratic [1]	X	X
		Eco [3]	X	X
Sensorless vector control [4] SLVC	MS-Velocity mode [-2]		X	X
Servo control ASM [2] (With encoder)	MS-Velocity mode [-2]			X

#### VFC open loop (Linear / quadratic)

Typical for AC induction motors. Suitable for many general applications like conveyors, pumps, fans, etc. No motor feedback is needed.



- See the following chapters:  
“6.5.2 V/f: Curve setting”, page 59  
“6.5.3 V/f: Slip compensation”, page 60  
“6.5.4 V/f: Frequency boost”, page 60

#### VFC Eco

Energy Saving Control for Asynchronous Motor (reduction of copper losses).

1. Set the motor control mode:  
P300:0 to “VFC open Loop [6]”
2. Set the V/f characteristic shape:  
P302:0 to “Eco [3]”
3. Advanced Motor setup:  
Set motor parameter (6.5.12 Motor parameter, page 65) or select the motor out of the Lenze catalogue (In case of a Lenze motor & Easy Starter).
4. Set VFC-ECO Minimum Voltage:  
P330:1 Set VFC-ECO Minimum Voltage



- See “6.5.2 V/f: Curve setting” on page 59

## 6 Function & parameter description

Group 3 – Motor control

---

### Sensorless vector control (SLVC)

For higher performance on torque response and speed regulation the SLVC can be used. To use this mode the motor parameter and the motor identification mode is required. No motor feedback is needed.

1. Set the motor control mode:  
P300:0 to “Sensorless vector control [4]”
2. Advanced Motor setup:  
Set motor parameter (6.5.12 Motor parameter, page 65) or select the motor out of the Lenze catalogue (In case of a Lenze motor & Easy Starter).

#### NOTICE!

For the usage of SLVC the following restrictions apply:

- ▶ Only for asynchronous motors
- ▶ Only permissible for one single motor
- ▶ Not Permissible for hoists
- ▶ The connected motor may be maximum two power classes lower than the motor assigned to the inverter

---

### Servo control (ASM)

Vector controlled servo control (with encoder) for asynchronous motors. Generally, the servo control offers the same advantages as the sensorless vector control (SLVC) with increased speed regulation performance.

1. Set the motor control mode:  
P300:0 to “Servo control ASM [2]”
2. Advanced Motor setup:  
Set motor parameter (6.5.12 Motor parameter, page 65) or select the motor out of the Lenze catalogue (In case of a Lenze motor & Easy Starter).
3. Encoder setup (6.5.16 HTL Encoder setup, page 67)

## 6 Function & parameter description

Group 3 – Motor control

### Functions:

	<b>Index</b>	<b>Display Code</b>	<b>VFC open loop [6]</b>	<b>SLVC [4]</b>	<b>Servo control ASM [2]*</b>
6.5.8 Switching frequency	0x2939:0	P305:0	X	X	X
6.5.2 V/f: Curve setting	0x2B00:0 0x2B01:X	P302:0 P303:X	X		
6.5.3 V/f: Slip compensation	0x2B09:X	P315:X	X		
6.5.4 V/f: Frequency boost	0x2B12:X	P316:X	X		
6.5.11 Skip frequency	0x291F:X	P317:X	(X)	X	X
6.5.5 V/f: Oscillation damping	0x2B0A:X	P318:X	(X)		
6.5.6 V/f: Override point of field weakening	0x2B0C:X	P319:X	(X)		
6.5.12 Motor parameter	0x2C01:X 0x6075:0	P320:X P323:0	(X)	X	X
6.5.13 Speed limitation	0x6080:0	P322:0	(X)	X	X
6.5.14 Current limitation	0x6073:0	P324:0	(X)	X	X
0	0x6076:0 0x6072:0	P325:0 P326:0		X	X
Torque limitation					

(X) Optional

<b>P300:0</b>	<b>0x2C00:0</b>	<b>Motor control mode</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
2: Servo Control ASM (*) 4: Sensorless vector control <b>6: VFC open loop</b>		Selection of the motor control mode			
<b>P301:0</b>	<b>0x6060:0</b>	<b>Modes of operation</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
-2: <b>MS-Velocity mode</b> 0: Mode no change/assigned 2: Velocity mode (vl)		Selection of the operation mode of the inverter <b>-2: MS-Velocity mode: (Manufacturer specific velocity mode)</b> Speed controlled motor with optional PID (Normal operating mode)  <b>0: Mode no change/assigned</b> No operation mode selected. Drive disabled.  <b>2: Velocity mode (vl):</b> CiA402 velocity mode. Control word 0x6040 is following CiA402 standard			

## 6 Function & parameter description

Group 3 – Motor control

### 6.5.2 V/f: Curve setting




Fig. 18: V/F mode

P302:0	0x2B00:0	V/f characteristic shape	i510	i550	R/W
<b>0: Linear</b> 1: Quadratic 3: Eco		Configuration of V/f shape <b>0: Linear</b> The curve has a constant V/f ratio which provides constant torque in the motor. V/f curves are used in many general applications. <b>1: Quadratic</b> The curve V/f is a quadratic function. This is used for fan or pump applications. <b>3: Eco</b> Energy Saving Control for Asynchronous Motor			
<b>P303:1</b>	<b>0x2B01:1</b>	<b>Base Voltage</b>	i510	i550	R/W
0 ... [Type Code dependent] ... 5000 V		V/f Base Voltage To be set to motor nominal voltage			
<b>P303:2</b>	<b>0x2B01:2</b>	<b>Base Frequency</b>	i510	i550	R/W
0 ... [Type Code dependent] ... 599 Hz		V/f Base Frequency To be set to motor nominal frequency			
<b>P330:1</b>	<b>0x2B0D:1</b>	<b>Minimum voltage</b>	i510	i550	R/W
20 ... [20] ... 100 %		Minimum voltage (Only used for Eco Mode) The efficiency range of VFC Eco is limited by the standard U/f curve and the VFC Eco curve. (See graphic above) This parameter describes the operating point in relation to a chosen percentage value of Base voltage (P303:1) at Base frequency (P303:2). See graphic above.			

## 6 Function & parameter description

Group 3 – Motor control

### 6.5.3 V/f: Slip compensation

In a standard AC induction motor, the shaft speed decreases as load increases, and increases as load decreases. Slip compensation is used to counteract changes in motor speed (slip) caused by changes in load.

#### 1. Setup the following motor parameter.

(Out of this parameters the inverter automatically calculates the nominal slip)

P320:4 Motor parameter: Rated speed

P320:5 Motor parameter: Rated frequency

#### 2. Setup the slip influence gain

100% means that full motor rated slip is applied with full torque. If the slip compensation is not accurate (Example: Motor data not accurate) the slip compensation can be adjusted with this value.

P315:1	0x2B09:1	Gain	i510	i550	R/W
-200.00 ... [100.00] ... 200.00 %	Configuration of the slip compensation influence. 100% means that full motor rated slip is applied with full torque.				
P315:2	0x2B09:2	Filter time	i510	i550	R/W
1 ... [5] ... 6000 ms	Configuration of the slip compensation filter time. The default is optimized for best slip speed loss recovery time performance of typical motors. If oscillation or instability occurs at full load (or near full load) then increasing the Slip Compensation Filter Time is recommended.				

### 6.5.4 V/f: Frequency boost

The voltage boost (Fixed or during Acceleration) can increase the starting torque for application with high inertia load, high friction loads.

P316:1	0x2B12:1	Fixed boost	i510	i550	R/W
0.0 ... [Type Code dependent] ... 20.0 %	The Fixed voltage boost increases the output voltage with the configured % of Base Voltage (P303:1)				
P316:2	0x2B12:2	Boost at acceleration	i510	i550	R/W
0.0 ... [0.0] ... 20.0 %	The Acceleration voltage boost increases the output voltage during acceleration in with the configured [%] of Base Voltage (P303:1)				

### 6.5.5 V/f: Oscillation damping

The oscillation damping function is used to reduce speed oscillations which can occur in unloaded or lightly loaded operation.

→ See Easy starter for setup and more information

### 6.5.6 V/f: Override point of field weakening

→ See Easy starter for setup and more information

## 6 Function & parameter description

Group 3 – Motor control

### 6.5.7 Rotation restriction

The rotation of the motor can be restricted to forward only.



See chapter “6.2.4 Rotation direction”, page 42

P304:0	0x283A:0	Rotation restriction	i510	i550	R/W
0: Forward only <b>1: Forward and reverse</b>		<p>The inverter can be limited to Forward (FWD) rotation only. This affects the final output setpoint for velocity and PID setpoint</p> <p><b>Note:</b> This command only prevents negative velocity setpoints. Therefore it is still possible that the motor runs reverse (Example: Wrong wiring).</p>			

### 6.5.8 Switching frequency

The inverter output is DC voltage that is sine-coded pulse width modulated (PWM) to approximate variable frequency AC voltage. The frequency of the PWM pulses is adjustable. This adjustment is called the PWM switching frequency.

#### General:

- Higher switching frequencies will result in less audible noise but will cause the inverter to generate more heat and operate less efficiently.
- Lower switching frequencies will result in more audible noise but will cause decreased earth leakage current, increased inverter efficiency and increased ambient operating temperature range.

P305:0	0x2939:0	Switching frequency	i510	i550	R/W
1: 4kHz var. / optimized		Definition of the Switching Frequency			
2: 8kHz var. / optimized		<b>1, 2, 3:</b> Optimized for best inverter performance (symmetrical modulation)			
3: 16kHz var. / optimized		Variable switching frequency: Inverter reduces the switching frequency if output current or inverter temperature are too high. Minimal Switching Frequency is limited to 2 kHz.			
5: 2kHz fix / optimized		<b>5, 6, 7, 8:</b> Optimized for best inverter performance (symmetrical modulation)			
6: 4kHz fix / optimized		Switching frequency is fixed.			
7: 8kHz fix / optimized		<b>11, 12, 13:</b> Optimized for best inverter efficiency (asymmetrical modulation).			
8: 16kHz fix / optimized		Variable switching frequency: Inverter reduces the switching frequency if output current or inverter temperature are too high. Minimal Switching Frequency is limited to 2 kHz.			
11: 4kHz var. / min. Pv		<b>15, 16, 17, 18:</b> Optimized for best inverter efficiency (asymmetrical modulation).			
12: 8kHz var. / min. Pv		Switching frequency is fixed.			
13: 16kHz var. / min. Pv		<b>21, 22, 23:</b> Optimized for best inverter performance (symmetrical modulation)			
15: 2kHz fix / min. Pv		Variable switching frequency: Inverter reduces the switching frequency if output current or inverter temperature are too high. Minimal Switching Frequency is limited to 2 kHz.			
16: 4kHz fix / min. Pv					
17: 8kHz fix / min. Pv					
18: 16kHz fix / min. Pv					
<b>21: 8kHz var./ opt./4kHz min.</b>					
22: 16kHz var./opt./4kHz min.					
23: 16kHz var./opt./8kHz min					
31: 8kHz var./ Pv/4kHz min.					
32: 16kHz var./ Pv/4kHz min.					
33: 16kHz var./ Pv/8kHz min.					

## 6 Function & parameter description

### Group 3 – Motor control

	output current or inverter temperature are too high. Minimal Switching Frequency is limited to 4 kHz or 8 kHz  <b>31, 32, 33:</b> Optimized for best inverter efficiency (asymmetrical modulation). Variable switching frequency: Inverter reduces the switching frequency if output current or inverter temperature are too high. Minimal Switching Frequency is limited to 4 kHz or 8 kHz
--	--

#### 6.5.9 Motor thermal overload (i2xt)

The function monitors the thermal power dissipation from the measured motor currents on the basis of a mathematical model. This can be used for motor overload protection. It is only usable for functional protection, i.e. to guarantee the service life time of the motor. It is not suitable as safety relevant protection against energy induced hazards.

##### DANGER!

###### **Fire hazard from motor overload**

Additional means must be provided to prevent fire hazards arising from motor overload

- ▶ Independent temperature monitoring of the motor with shut down

##### DANGER!

###### **Uncontrolled motor behavior**

If the motor overload occurs the inverter stops modulating and no torque is available on the motor. On motors under load without holding brake this can lead to uncontrolled motor movements.

- ▶ Use the inverter only under the specified load conditions.

P308:1	0x2D4B:1	Maximum utilisation [60 s]	i510	i550	R/W
30 ... [150] ... 200 %		Configuration of the I2xt trip time. If the motor is running with nominal current (P323) for longer than the configured trip time, the inverter will trip according the configured reaction.			
P308:2	0x2D4B:2	Speed compensation	i510	i550	R/W
0: On 1: Off		Slow speed compensation (<40 Hz) <b>0: On</b> The over load trip time on motor is reduced to compensate the decreased cooling of self-cooled AC induction motors when running at slow speed. <b>1: Off</b> Function disabled, no reduction.  <b>Notes:</b> - For compliance with UL the user must enable this function or use an appropriate PTC to protect the motor. - Function to protect motors at speed lower than 40 Hz			
P308:3	0x2D4B:3	Error response	i510	i550	R/W
3:Fault (Reference see P310:1)		Configuration of the i2xt over load fault reaction. If the trip level is reached to motor will react as defined. <b>Notes:</b> - For compliance with UL the user must enable this function or use an appropriate PTC to protect the motor.			

## 6 Function & parameter description

Group 3 – Motor control

### 6.5.10 Motor temperature sensor

For detecting and monitoring of the motor temperature, a PTC thermistor (DIN 44081 Single, DIN 44082 Triplet) or a thermal contact (NC contact) can be connected to the terminals T1 and T2.  
Stop!

#### NOTICE!

The inverter can only evaluate one PTC thermistor!  
Do not connect several PTC thermistors in series or parallel.

- ▶ If several motors are operated on one inverter, use thermal contacts (NC contacts) connected in series.
- ▶ To achieve full motor protection, an additional temperature monitoring with separate evaluation must be installed.



This function is only available with i550. It is recommended to always use this function if the motor is equipped with a PTC thermistors or thermo contact.

P309:2	0x2D49:2	Reaction	i550	R/W
3:Fault (Reference see P310:1)		<p>Motor temperature sensor fault reaction</p> <p><b>0: No response</b> No reaction on the inverter</p> <p><b>1: Warning</b> Warning will be displayed. Inverter will continue operation normally.</p> <p><b>2: Trouble</b> Inverter will go to Trouble state and ramp down the motor with the Quick Stop Ramp time.</p> <p><b>3: Fault</b> Inverter will go to Fault state and stop the motor with a coast stop.</p>		

## 6 Function & parameter description

### Group 3 – Motor control

#### 6.5.11 Skip frequency

Three skip frequencies are available to lock out critical frequencies that cause mechanical resonance.

**Example:**

Skip frequency 20 Hz

Skip bandwidth 10 Hz

Frequency area 15 Hz .. 25 Hz is skipped



Skip frequencies are absolute.

Disable function: Skip bandwidth = 0

Skip frequencies cannot be set to include 0Hz (i.e. if 2Hz was set as a skip frequency and a bandwidth of 4Hz or greater was selected, the skip range is ignored).




Fig. 19: Skip frequency

P317:1	0x291F:1	Skip frequency 1	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Skip frequency 1			
P317:2	0x291F:2	Skip bandwidth 1	i510	i550	R/W
0.0 ... [0.0] ... 10.0 Hz		Skip bandwidth 1			
P317:3	0x291F:3	Skip frequency 2	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Skip frequency 2			
P317:4	0x291F:4	Skip bandwidth 2	i510	i550	R/W
0.0 ... [0.0] ... 10.0 Hz		Skip bandwidth 2			
P317:5	0x291F:5	Skip frequency 3	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Skip frequency 3			
P317:6	0x291F:6	Skip bandwidth 3	i510	i550	R/W
0.0 ... [0.0] ... 10.0 Hz		Skip bandwidth 3			

## 6 Function & parameter description

Group 3 – Motor control

### 6.5.12 Motor parameter



For the mode “Sensorless vector control”, “Servo Control ASM”, and “VFC Eco mode” the parameter set-up and calibration is necessary.

For “VFC open loop” linear/quadratic it is not necessary but can increase the control behavior.

Two ways are possible to setup the motor parameter:

#### Lenze motor & Easy Starter

Select the motor out of the Lenze catalogue

#### Third party motor or Keypad

Set the motor parameter described below and execute the “identification” (P327:4) or “estimation” (P327:4)

P320:4	0x2C01:4	Rated speed	i510	i550	R/W
50 ... [1450] ... 50000 rpm		Rated motor nominal speed (motor nameplate) Automatically set if Lenze Motor is selected from catalog.			
P320:5	0x2C01:5	Rated frequency	i510	i550	R/W
1.0 ... [50.0] ... 1000.0 Hz		Rated motor nominal frequency (motor nameplate) Automatically set if Lenze Motor is selected from catalog.			
P320:6	0x2C01:6	Rated power	i510	i550	R/W
-- ... [Type Code dependent] ... -- kW		Rated motor nominal power (motor nameplate) Automatically set if Lenze Motor is selected from catalog.			
P320:7	0x2C01:7	Rated voltage	i510	i550	R/W
-- ... [Type Code dependent] ... -- V		Rated motor nominal voltage (motor nameplate) Automatically set if Lenze Motor is selected from catalog.			
P320:8	0x2C01:8	Rated cosine phi	i510	i550	R/W
0.00 ... [0.80] ... 1.00		Rated motor nominal cos phi (motor nameplate) Automatically set if Lenze Motor is selected from catalog.			
P323:0	0x6075:0	Motor rated current	i510	i550	R/W
0.001 ... [Type Code dependent] ... 500.000 A		Rated motor nominal cos phi (motor nameplate) Automatically set if Lenze Motor is selected from catalog.			
P335:1	0x2910:1	Motor	i510	i550	R/W
0.00 ... [Type Code dependent] ... 20000000.00 kg cm <sup>2</sup>		Moment of inertia of motor (Set it based on Motor) Automatically set if Lenze Motor is selected from catalog.			
P335:2	0x2910:2	Load	i510	i550	R/W
0.00 ... [Type Code dependent] ... 20000000.00 kg cm <sup>2</sup>		Moment of inertia of load (Set it based on Application)			
P	0x2910:3	Coupling	i510	i550	R/W
0: Stiff 1: Elastic 2: With backlash		Coupling of motor and load (Set it based on Application)			
P327:4	0x2822:4	Motor identification	i510	i550	R/W
0 ... [0] ... 1		Motor identification (Energized) 1: Enables the motor identification (Energized). After setting the parameter a valid Run/Start command starts the identification. For that cycle DI1 (Run / Stop Command). This initiates the energized identification. The identification may take several seconds/minutes and measures the motor characteristic and calculates motor control parameters (Speed/Current control loop) based on the identified parameters.			

## 6 Function & parameter description

Group 3 – Motor control

		During the identification the blue status LED is ON. The blue LED flashing and the red LED OFF indicate that the identification was successfully finished. The red LED ON indicates that the identification failed.			
P327:5	0x2822:5	<b>Motor estimation</b>	i510	i550	R/W
0 ... [0] ... 1		<p>Motor estimation (Non-Energized) 1: Enables the motor estimation. The estimation takes less than 1s and calculates the equivalent circuit data and the motor control parameters (Speed/Current control loop) based on the motor rated values.</p> <p>The blue LED flashing and the red LED OFF indicate that the calibration was successfully finished. The red LED ON indicates that the calibration failed.</p>			

### 6.5.13 Speed limitation

The overall maximal speed can be limited.



The speed limitation is active after the ramp generator!

P322:0	0x6080:0	<b>Max motor speed</b>	i510	i550	R/W
0 ... [6075] ... 480000 rpm		Overall Maximum motor speed			

### 6.5.14 Current limitation

The maximum current can be limited. If the current limit is reached the output frequency is reduced in motor operation and increased in generator operation. When the over current condition passes, the inverter will return to normal operation and reaccelerate to the set point.

If the limitation cannot correct the condition and the inverter remains in current limit for too long, it will trip with I2T motor error.

P324:0	0x6073:0	<b>Max current</b>	i510	i550	R/W
0.0 ... [200.0] ... 3000.0 %		Maximum motor current in % of P323:0			

## 6 Function & parameter description

Group 3 – Motor control

### 6.5.15 Torque limitation

The maximum torque can be limited.



Note: The limitation is not active in V/f mode!

P325:0	0x6076:0	Motor rated torque	i510	i550	R/W
0.001 ... [Type Code dependent] ... 1000.000 Nm		Motor rated torque in [Nm]			
P326:0	0x6072:0	Maximum Torque in [%]	i510	i550	R/W
0.0 ... [250.0] ... 3000.0 %		Maximum motor torque in % of P325:0			
P329:1	0x2D67:1	Torque monitor:response	i510	i550	R/W
<b>0: No reaction</b> 1: Warning 2: Trouble 3: Fault		Torque limitation fault reaction <b>Note:</b> Status bit "MotorTorqueMax" is set independently of the selected response.			
P329:2	0x2D67:2	Torque monit:Shutter delay	i510	i550	R/W
0.000 ... [0.000] ... 10.000 s		Torque limitation fault delay			

### 6.5.16 HTL Encoder setup

A HTL encoder can be connected to the DI3 and DI4 of the inverter. The encoder can be used for:

- As a motor encoder for speed control
- As a process encoder as a setpoint (e.g. true web speed for winding application) or as an actual value for e.g. PID Controller

#### Setup:

1. Select the encoder in P410:2
2. Set the encoder increment/revolution P341:1
3. Select the function of the encoder:

P600:2 Feedback PID / P201:2 PID setpoint / P201:1 Frequency setpoint

**Note:** If SC or SLPSM mode is selected the encoder is automatically assigned as feedback.

The actual encoder feedback is displayed in 0x2C42:6

P341:1	0x2C42:1	Increments/ revolution	i550	R/W
1 ... [128] ... 16384		Set the number of increments per revolution of the connected encoder (See data sheet of the encoder)		
P410:2	0x2630:2	Mode selection	i510	i550
<b>0: Digital input</b> 1: Encoder (AB) (*)		Mode selection for digital input functionalities (DI4 / DI3)		
P	0x2C42:6	Actual velocity	i550	R
-- ... [Actual value] ... -- rpm		Actual velocity feedback of encoder		

## 6 Function & parameter description

Group 3 – Motor control

### 6.5.17 Overspeed monitoring

The inverter contains Motor Overspeed detection. If the specified threshold is exceeded, the inverter will react as defined.



The overspeed monitoring is only active if the motor is in motoring mode.

P350:1	0x2D44:1	Threshold	i510	i550	R/W
50 ... [8000] ... 50000 rpm		Overspeed threshold			
P350:2	0x2D44:2	Reaction	i510	i550	R/W
<b>3:Fault</b> (Reference see P310:1)		Overspeed fault reaction			

### 6.5.18 Overcurrent monitoring

The inverter monitors the output current and compares it to a threshold value. If the specified threshold is exceeded, the inverter will react as defined.



This parameter can also be set and overwritten by selecting a Motor from the catalog or by using the non-energized calibration process. The user should adjust this default value for proper protection.

P353:1	0x2D46:1	Threshold	i510	i550	R/W
0.0 ... [Type Code dependent] ... 1000.0 A		Overcurrent threshold			
P353:2	0x2D46:2	Reaction	i510	i550	R/W
<b>3:Fault</b> (Reference see P310:1)		Overcurrent fault reaction			

## 6 Function & parameter description

### Group 4 – I/O setup

## 6.6 Group 4 – I/O setup

### 6.6.1 Function list (Run/Stop/Start/Jog/Reverse)

Parameters P400:1...P400:49 contain the main functions of the inverter. The function can be assigned to a trigger. If the trigger is activated the function is executed. The digital trigger values can come from external sources (Digital Inputs, Network, etc.) and internal sources (Inverter status, faults, etc.) It is possible to assign more than one function to a single trigger.

#### Basic functionalities:

- **Inverter enable**  
Enables the inverter. Signal must have the state TRUE (by Input or setting) to be able to start the motor.
- **Run/Stop**  
Enables the running of the motor. Can be used as single signal or in combination with the signals Start Forward / Start Reverse. Signal must have the state TRUE (by Input or setting) to be able to start the motor.
- **Start Forward / Start Reverse**  
Used to start the motor (Positive edge triggered). Stop is down with the **Run/Stop** signal.
- **Run Forward / Run Reverse**  
Used to run and stop the motor (Maintained signals)
- **Rotation inversion**  
Inverts the speed setpoint
- **JOG Forward / JOG Reverse**  
JOG the motor with a fixed speed. Jog has higher priority than Run/Stop, Start or Run commands.
- **Fault Reset**  
For a successful reset of a fault it is necessary to correct the condition that caused the fault first. Afterwards there are different possibilities to reset the fault:

Function to reset fault:	Parameter	Transition
Reset fault	P400:4	FALSE > TRUE (rising edge)
Inverter enable	P400:1	TRUE > FALSE (Falling Edge)
Run/Stop	P400:2	TRUE > FALSE (Falling Edge)
Keypad STOP	-	FALSE > TRUE (Rising edge)



See chapter “6.2.2 Control Source”, page 38

See chapter “6.2.3 Control examples”, page 39



In **Flexible** Control mode (P200:0) either **Inverter enable (P400:1)** or **Run/Stop (P400:2)** must be assigned to I/O to ensure that the drive can always be stopped!

(Exception: Inverter is controlled from network, **Network enable (P400:37)** is HIGH)

#### NOTICE!

The JOG functions have priority over Stop commands. If the inverter is currently JOGGING, pressing the STOP key on the keypad or triggering STOP command will NOT stop the motor!

## 6 Function & parameter description

### Group 4 – I/O setup

P400:1	0x2631:1	Inverter enable	i510	i550	R/W
0: Not connected <b>1: Constant TRUE</b> 11: Digital input 1 12: Digital input 2 13: Digital input 3 14: Digital input 4 15: Digital input 5 16: Digital input 6 (*) 17: Digital input 7 (*) 50: Running 51: Ready to run 53: Stop active 54: Quick stop active 58: Device warning 59: Device fault active 60: Heatsink temp. warning 69: Rotation inverted 70: Frequency thld exceeded 71: Actual speed = 0 78: Current thld exceeded 79: Maximum torque 80: Follower signal loss 81: Error analog input 1 82: Error analog input 2 83: Loss of load 104: Local control active 105: Remote control active 106: Manual setpoint active 107: Automatic setpoint active		<p><b>State:</b> TRUE enables the inverter. FALSE inhibits the inverter and the motor will coast stop.</p> <p><b>Note:</b> Signal must have the state TRUE (by Input or setting) to be able to start the motor</p>			
P400:2	0x2631:2	Run/Stop	i510	i550	R/W
<b>11:Digital input 1</b> (Reference see P400:1)		<p>Inverter Run/Stop signal</p> <p><b>State:</b> TRUE will make the inverter ready to run FALSE will stop the motor according to the defined stop method</p> <p><b>Note:</b> Set 01 TRUE to disable the function</p> <p>Signal must have the state TRUE (by Input or setting) to be able to start the motor</p>			
P400:3	0x2631:3	Quick stop	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		<p>The quick stop function works as pause or zero speed function. If the quick stop is applied the motor will ramp down with the defined QSP ramp.</p> <p><b>Note:</b> 0: FALSE disables this functionality</p>			
P400:4	0x2631:4	Reset fault	i510	i550	R/W
<b>12:Digital input 2</b> (Reference see P400:1)		<p>Trigger for fault reset FALSE-&gt;TRUE transition the faults will be reset.</p>			

## 6 Function & parameter description

Group 4 – I/O setup

P400:6	0x2631:6	Start forward (CW)	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		<p>Start forward signal (Edge triggered)</p> <p><b>State:</b> Transition FALSE--&gt;TRUE will start the motor forward</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>- Use P400:2 “Run/Stop” signal to stop the motor</li> <li>- Set the signal to 0: FALSE to disable the function</li> <li>- If a bipolar input (-10V..+10V) is used the direction is controlled by the reference signal</li> </ul>			
P400:7	0x2631:7	Start reverse (CCW)	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		<p>Start reverse signal (Edge triggered)</p> <p><b>State:</b> Transition FALSE--&gt;TRUE will start the motor forward</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>- Use P400:2 “Run/Stop” signal to stop the motor</li> <li>- Set the signal to 0: FALSE to disable the function</li> <li>- If a bipolar input (-10V..+10V) is used the direction is controlled by the reference signal</li> </ul>			
P400:8	0x2631:8	Run forward (CW)	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		<p>Run forward signal (Maintained signal)</p> <p><b>State:</b> TRUE will start the motor forward The last activated signal of run forward and run reverse defines the direction! FALSE of Run Forward and Run Reverse will stop the motor according to the defined stop method</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>- Set the signal to 0: FALSE to disable the function</li> <li>- If a bipolar input (-10V..+10V) is used the direction is controlled by the reference signal</li> </ul>			
P400:9	0x2631:9	Run reverse (CCW)	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		<p>Run reverse signal (Maintained signal)</p> <p><b>State:</b> TRUE will start the motor reverse The last activated Signal of Run Forward and Run Reverse defines the direction! FALSE of Run Forward and Run Reverse will stop the motor according to the defined stop method</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>- Set the signal to 0: FALSE to disable the function</li> <li>- If a bipolar input (-10V..+10V) is used the direction is controlled by the reference signal</li> </ul>			

## 6 Function & parameter description

Group 4 – I/O setup

P400:10	0x2631:10	Jog forward (CW)	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		<p>JOG Forward with preset frequency 5</p> <p><b>State:</b> TRUE will start the motor forward with preset frequency 5 FALSE will stop the motor If JOG forward and JOG reverse are applied at the same time the motor will stop and the JOG has to be retriggered!</p> <p><b>WARNING:</b> The JOG functions have priority over Stop commands. If the inverter is currently JOGGING, pressing the STOP key on the keypad or triggering STOP command will NOT stop the motor!</p>			
P400:11	0x2631:11	Jog reverse (CCW)	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		<p>JOG Forward with preset frequency 6</p> <p><b>State:</b> TRUE will start the motor reverse with preset frequency 6 FALSE will stop the motor If JOG forward and JOG reverse are applied at the same time the motor will stop and the JOG has to be retriggered!</p> <p><b>WARNING:</b> The JOG functions have priority over Stop commands. If the inverter is currently JOGGING, pressing the STOP key on the keypad or triggering STOP command will NOT stop the motor!</p>			
P400:12	0x2631:12	Keypad control	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		<p>Keypad Selection for Start/Stop command</p> <p><b>State:</b> TRUE: Start and Stop commands coming from the keypad FALSE: Start and Stop commands are defined by the connection list</p>			
P400:13	0x2631:13	Invert rotation	i510	i550	R/W
<b>13:Digital input 3</b> (Reference see P400:1)		<p>Rotation inversion signal</p> <p><b>State:</b> TRUE: target reference setpoint is inverted (i.e. times -1) FALSE: the target reference setpoint is not inverted</p>			

## 6 Function & parameter description

Group 4 – I/O setup

### 6.6.2 Setpoint selection

#### Setpoint Priority:

The priority of the setpoint is according the following list:

Terminal/Flexible or Keypad control (P400:37 = False)	Network mode (P400:37 = TRUE)
<p>1. <b>Trigger for Setpoint Source (Connection List)</b> <b>P400:14 – P400:25</b> In order of the selected trigger            1. 1: TRUE            2. 11: Digital Input 1 (DI1)            3. 12: Digital Input 2 (DI2)            4. 13: Digital Input 3 (DI3)</p> <p>2. <b>Default Setpoint</b>  <b>Speed</b>      <b>P201:1 (0x2860:1)</b>  <b>PID</b>          <b>P201:2 (0x2860:2)</b></p>	<p>1. <b>Setpoint/Network setpoint controlled with:</b>            AC Drive Control Word            C135 Control Word            NETWordIN1</p> <p>2. <b>Default Setpoint</b>  <b>Speed</b>      <b>P201:1 (0x2860:1)</b>  <b>PID</b>          <b>P201:2 (0x2860:2)</b></p>

**i** In Network mode (P400:37 = TRUE) the triggers P400:14 – P400:25 are not active.  
To select the network as setpoint source in network mode (P400:37 = TRUE) use the “Default setpoint source” (P201:1-2) or the corresponding control bits (AC Drive Control Word, C135 Control Word, NET-WordIN1).

**i** The actual control setpoint source can be seen in P125:2

**→** See chapter “6.4.2 Default setpoint”, page 50  
See chapter “6.2.1 Setpoint structure / operation mode”, page 36

P400:14	0x2631:14	AI1 setpoint selection	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		Selects Analog input 1 as setpoint source			
P400:15	0x2631:15	AI2 setpoint selection	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		Selects Analog input 2 as setpoint source			
P400:16	0x2631:16	Keypad setpoint selection	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		Selects Keypad as setpoint source			
P400:17	0x2631:17	Setpoint = Network	i510	i550	R/W
<b>0: Not connected</b> 116: Netw.Ref active (Other Reference see P400:1)		Selects Network as setpoint source (SW 02.01) in terminal mode. <b>Note:</b> In Network mode (P400:37 = TRUE) the triggers P400:14 – P400:25 are not active. To select the network as setpoint source in network mode (P400:37 = TRUE) use the “Default setpoint source” (P201:1-2) or the corresponding control bits (AC Drive Control Word, C135 Control Word, NET-WordIN1).  116: TRUE if AC Drive Control Word (0x400B:1) bit 6 is active			
P400:18	0x2631:18	Preset selection bit 0	i510	i550	R/W
<b>14:Digital input 4</b> (Reference see P400:1)		Preset frequency setpoint selection bit 0 Combination Example: bit0 and bit2 result in preset frequency 5			

## 6 Function & parameter description

### Group 4 – I/O setup

P400:19	0x2631:19	Preset selection bit 1	i510	i550	R/W		
15:Digital input 5 (Reference see P400:1)		Preset frequency setpoint selection bit 1					
P400:20	0x2631:20	Preset selection bit 2	i510	i550	R/W		
0:Not connected (Reference see P400:1)		Preset frequency setpoint selection bit 2					
P400:21	0x2631:21	Preset selection bit 3	i510	i550	R/W		
0:Not connected (Reference see P400:1)		Preset frequency setpoint selection bit 3					

### 6.6.3 Motor Potentiometer

With the motor potentiometer mode (MOP) the setpoint is controlled with the two triggers Increase and Decrease (Example: 2 digital inputs).

- The MOP is enabled by trigger P400:25 or can be set as default setpoint source.
- Motor potentiometer up** TRUE: Setpoint will increase with acceleration time 2
- Motor potentiometer down** TRUE: Setpoint will decrease with deceleration time 2
- MOP is increasing/decreasing the setpoint according acceleration/deceleration time 2. The motor is following the setpoint with acceleration/deceleration time 1 also in MOP-mode.
- If both triggers are TRUE or FALSE at the same time the setpoint will remain constant.
- The start value of the MOP is defined with P413:0

P400:23	0x2631:23	Motor potentiometer up	i510	i550	R/W		
0:Not connected (Reference see P400:1)		State TRUE will increase the speed setpoint in MOP-Mode.					
P400:24	0x2631:24	Motor potentiometer down	i510	i550	R/W		
0:Not connected (Reference see P400:1)		State TRUE will decrease the speed setpoint in MOP-Mode.					
P400:25	0x2631:25	Motor potentiometer select	i510	i550	R/W		
0:Not connected (Reference see P400:1)		Trigger to enable the MOP-Mode. After enabling the speed is controlled by digital inputs MOP up / MOP down.					
P413:0	0x4003:0	Motor pot. start mode	i510	i550	R/W		
0: Last value 1: Init Value 2: Minimum Value		Defines the start setpoint value when MOP is enabled. <b>0: Last value</b> MOP starts with the last MOP set value. <b>1: Init Value</b> MOP starts with the value in P414:1 or P414:2 <b>2: Minimum Value</b> MOP starts with minimum frequency (P210:0) or minimum PID value (P605:1)					
P414:1	0x4004:1	Speed	i510	i550	R/W		
0.0 ... [0.0] ... 599.0 Hz		Frequency start value for MOP-Mode <b>Note:</b> Only active if P413:0 is set to 1					
P414:2	0x4004:2	Process controller (PID)	i510	i550	R/W		
-300.00 ... [0.00] ... 300.00 PUnit		Process controller start value for MOP-Mode <b>Note:</b> Only active if P413:0 is set to 1					

## 6 Function & parameter description

Group 4 – I/O setup

### 6.6.4 User defined faults

Two user defined fault can be configured. (Example: To stop motor in case of process fault) If a user defined fault occurs the inverter goes into fault state. After clearing the fault the resetting of the inverter is required.

P400:43	0x2631:43	User-defined fault 1	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		Configuration of user defined fault 1			
P400:44	0x2631:44	User-defined fault 2	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		Configuration of user defined fault 2			

### 6.6.5 Digital input configuration

The digital input are used for control operations. The following configurations are available for the digital input signals:

- Assertion Level (Only i550)**  
The i550 digital inputs can be used with PNP or NPN signals. The setting applies for all digital inputs!
- Signal inversion**  
Every digital Input can be inverted individually
- Connection list / Function**  
In general a digital input is assigned to a specific function like Start Reverse or Quick stop. With that it is possible to have more than one function on the same digital input.



See chapter 6.6.1 Function list (Run/Stop/Start/Jog/Reverse), page 69 for the configurable functions.

P410:1	0x2630:1	Assertion level	i510	i550	R/W
<b>0: LOW active</b> <b>1: HIGH active</b>		Input signal assertion for PNP/NPN selection <b>0: Low</b> For NPN input signals <b>1: High</b> For PNP input signals			
P410:2	0x2630:2	Mode selection	i510	i550	R/W
<b>0: Digital input</b> 1: Encoder (AB) (*)		Mode selection for digital input functionalities (DI4 / DI3): 0: DI4 / DI3 = digital inputs 1: Encoder (AB)			
P411:1	0x2632:1	Digital input 1	i510	i550	R/W
<b>0: Not inverted</b> 1: Inverted		Inversion of Digital Input			
P411:2	0x2632:2	Digital input 2	i510	i550	R/W
<b>0: Not inverted</b> 1: Inverted		Inversion of Digital Input			
P411:3	0x2632:3	Digital input 3	i510	i550	R/W
<b>0: Not inverted</b> 1: Inverted		Inversion of Digital Input			
P411:4	0x2632:4	Digital input 4	i510	i550	R/W
<b>0: Not inverted</b> 1: Inverted		Inversion of Digital Input			

## 6 Function & parameter description

Group 4 – I/O setup

P411:5	0x2632:5	Digital input 5	i510	i550	R/W
<b>0: Not inverted</b>		Inversion of Digital Input			
1: Inverted					
P411:6	0x2632:6	Digital input 6 (*)		i550	R/W
<b>0: Not inverted</b>		Inversion of Digital Input			
1: Inverted					
P411:7	0x2632:7	Digital input 7 (*)		i550	R/W
<b>0: Not inverted</b>		Inversion of Digital Input			
1: Inverted					

### 6.6.6 Frequency threshold setup

A frequency threshold can be used to trigger a function, a digital output or the relay. The trigger is referenced to actual inverter output frequency. This trigger is TRUE when the actual output frequency is above a programmable frequency threshold.

P412:0	0x4005:0	Frequency threshold	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Frequency threshold			

### 6.6.7 Digital output configuration

The digital outputs (Relay, DO) can be configured:

- Functionality can be selected
- Inversion of Output (Only Relay and DO)

P420:1	0x2634:1	Relay	i510	i550	R/W
0: Not connected		0: Not Connected / always false			
1: Constant TRUE		1: TRUE always			
11: Digital input 1		11-17: TRUE when corresponding digital input is asserted			
12: Digital input 2		34-49: TRUE when selected bit of the NETWordIn is high.			
13: Digital input 3		50: TRUE when the inverter is running.			
14: Digital input 4		FALSE when inverter is disabled, DC-Brake active, quick stopped and speed <0,2Hz, faulted or stopped.			
15: Digital input 5		51: TRUE when inverter not in Failure, Safety OK and DC link charged (SW 02.01)			
16: Digital input 6 (*)		52: TRUE when the inverter is enabled.			
17: Digital input 7 (*)		53: TRUE when inverter is enabled, output=0V, not running and not faulted			
34: NETWordIN2 - bit 0		54: TRUE when quick stop is selected and active.			
35: NETWordIN2 - bit 1		55: TRUE when Safe Torque OFF is active			
36: NETWordIN2 - bit 2		56: TRUE when the inverter has a fault condition.			
37: NETWordIN2 - bit 3		57: TRUE when the inverter has a fault condition that is locked and cannot be reset.			
38: NETWordIN2 - bit 4		58: TRUE when a warning is present.			
39: NETWordIN2 - bit 5		59: TRUE when a trouble condition is present.			
40: NETWordIN2 - bit 6		60: TRUE when the heat sink temperature exceeds the warning level			
41: NETWordIN2 - bit 7		65: TRUE when a PTC fault is detected.			
42: NETWordIN2 - bit 8		66: TRUE when a flying start or a restart is active			
43: NETWordIN2 - bit 9		67: TRUE when the DC brake is on.			
44: NETWordIN2 - bit 10		69: TRUE when output frequency is negative			
45: NETWordIN2 - bit 11		70: TRUE when the output frequency is > the frequency threshold			
46: NETWordIN2 - bit 12					
47: NETWordIN2 - bit 13					
48: NETWordIN2 - bit 14					
49: NETWordIN2 - bit 15					

## 6 Function & parameter description

### Group 4 – I/O setup

50: Running	(P412:0)				
<b>51: Ready for operation</b>	71: TRUE when the output frequency is zero +/- 0.01Hz				
52: Inverter enable	72: TRUE when the inverter reaches the commanded setpoint and set-point <> 0 Hz				
53: Stop active	73: TRUE when the PID feedback is equal to the programmed setpoint +/- 2%				
54: Quick stop active	74: TRUE when in Sleep mode				
55: Safe Torque Off	75: TRUE when a minimum alarm is triggered (reference to P608:1)				
56: Fault	76: TRUE when a maximum alarm is triggered (reference to P608:2)				
57: Fault interlocking	77: TRUE when no minimum/maximum alarm is active. (reference to P608:1 & P608:2)				
58: Device warning	78: TRUE when the actual motor current has exceeded the level in P324:0.				
59: Device fault active	79: TRUE when the actual torque has exceeded the level in P326:0, 0x60E0:0 or 0x60E1:0.				
60: Heatsink temp. warn. active	80: TRUE when AI1 / AI2 are configured for 4...20 mA, the setpoint source is active and the signal falls below 2 mA.				
65: PTC fault	81: TRUE when loss of the analog input 1 has been detected. P430:8-10				
66: Flying restart	82: TRUE when loss of the analog input 2 has been detected. P431:8-10				
67: DC brake active	83: TRUE when no load is detected				
69: Inverse rotation	104: TRUE when local (LOC) mode is active (local keypad START control)				
70: Frequency thld exceeded	105: TRUE when remote (REM) mode is active (all control sources EXCEPT keypad control)				
71: Actual speed = 0	106: TRUE when manual (MAN) mode is active (Keypad setpoint control)				
72: Setpoint speed reached	107: TRUE when automatic (AUTO) mode is active (All setpoint sources other than Keypad)				
73: PID feedback = setpoint	108: TRUE when parameter set #1 is loaded and active.				
74: Sleep mode on	109: TRUE when parameter set #1 is loaded and active.				
75: Minimum alarm	110: TRUE when parameter set #1 is loaded and active.				
76: Maximum alarm	111: TRUE when parameter set #1 is loaded and active.				
77: Minimum/Maximum alarm	112: TRUE after any parameter set 1...4 change-over has completed without error.				
78: At current limit	113: TRUE when any parameter set load fails.				
79: At torque limit	114: TRUE when on AC Drive control word (P592:1) Bit 5 = TRUE (specifically for AC Drive profile)				
80: Follower signal loss	115: TRUE when brake release signal is TRUE (either by auto trigger or manual trigger).				
81: Error analog input 1					
82: Error analog input 2					
83: Loss of load					
104: Local control active					
105: Remote control active					
106: Manual setpoint active					
107: Automatic setpoint active					
108: Parameter set 1 active					
109: Parameter set 2 active					
110: Parameter set 3 active					
111: Parameter set 4 active					
112: Parameter set load OK					
113: Parameter set load fail					
114: Network control					
115: Holding brake release					
<b>P420:2</b>	<b>0x2634:2</b>	<b>Digital output 1</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>115:Holding brake release</b> (Reference see P420:1)		Function of Digital Output 1 (Reference list see P420:1)			
<b>P420:3</b>	<b>0x2634:3</b>	<b>Digital output 2 (*)</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>56:Fault</b> (Reference see P420:1)		Function of Digital Output 2 (Reference list see P420:1)			
		Note: Only with Application IO			
<b>P421:1</b>	<b>0x2635:1</b>	<b>Relay</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0: Not inverted</b>		Inversion of Relay Output			
1: Inverted					

## 6 Function & parameter description

### Group 4 – I/O setup


P421:2	0x2635:2	Digital output 1	i510	i550	R/W		
0: Not inverted 1: Inverted		Inversion of Digital Output 1					
P421:3	0x2635:3	Digital output 2 (*)		i550	R/W		
0: Not inverted 1: Inverted		Inversion of Digital Output 2					
<b>Note:</b> Only with Application IO							

### 6.6.8 Analog input settings

The inverter is equipped with two analog inputs. These can be configured as reference or feedback signal.

The following settings are available:

- Input configuration
- Input filter time / Input Dead time
- Input monitoring function
- Input scaling



\*\* Availability of scaling depending on type of control unit.

P430:1	0x2636:1	AI 1 configuration	i510	i550	R/W		
0: 0...10VDC 1: 0...5VDC 2: 2...10VDC 3: -10...+10VDC (*) 4: 4...20mA 5: 0...20mA		Configuration of Analog input signal 1  <b>Note:</b> On i510 only current and unipolar voltage input available.					

## 6 Function & parameter description

### Group 4 – I/O setup

<b>P430:2</b>	<b>0x2636:2</b>	<b>Analog input 1: Min value [Hz]</b>	i510	i550	R/W
-1000.0 ... [0.0] ... 1000.0 Hz		Frequency scaling of the analog input Represents the minimum of the analog input value			
<b>P430:3</b>	<b>0x2636:3</b>	<b>Analog input 1: Max value [Hz]</b>	i510	i550	R/W
-1000.0 ... [50.0] ... 1000.0 Hz		Frequency scaling of the analog input Represents the maximum of the analog input value			
<b>P430:4</b>	<b>0x2636:4</b>	<b>Analog input 1: Min value [Punit/%]</b>	i510	i550	R/W
-300.00 ... [0.00] ... 300.00 PUnit/%		PID/Torque scaling of the analog input Represents the minimum of the analog input value			
<b>P430:5</b>	<b>0x2636:5</b>	<b>Analog input 1: Max value [Punit/%]</b>	i510	i550	R/W
-300.00 ... [100.00] ... 300.00 PUnit/%		PID/Torque scaling of the analog input Represents the maximum of the analog input value			
<b>P430:6</b>	<b>0x2636:6</b>	<b>Analog input 1: Filter time</b>	i510	i550	R/W
0 ... [10] ... 10000 ms		Analog input filter time constant			
<b>P430:7</b>	<b>0x2636:7</b>	<b>Analog input 1: Deadband</b>	i510	i550	R/W
0.0 ... [0.0] ... 100.0 %		Configuration of the deadband such that any input value below this percentage will be treated as 0Hz. (In % of Max Input Value) Example: Deadband 10% of 50Hz: -10V ... 10V Deadband -5Hz ... 5 Hz 0 ... 10V Deadband 0Hz ... 5 Hz			
<b>P430:8</b>	<b>0x2636:8</b>	<b>Analog input 1: Monitoring level</b>	i510	i550	R/W
-100.0 ... [0.0] ... 100.0 %		Monitoring condition of the analog input			
<b>P430:9</b>	<b>0x2636:9</b>	<b>Analog input 1: Monitoring action</b>	i510	i550	R/W
<b>0: Below level 1</b>		Monitoring condition of the analog input			
1: Above level 1					
<b>P430:10</b>	<b>0x2636:10</b>	<b>Analog input 1: Error response</b>	i510	i550	R/W
<b>3:Fault</b> (Reference see P310:1)		Fault reaction of the analog input monitoring.			
<b>P431:1</b>	<b>0x2637:1</b>	<b>AI2 configuration</b>	i510	i550	R/W
<b>0: 0...10VDC</b> 1: 0...5VDC 2: 2...10VDC 3: -10...+10VDC (*) 4: 4...20mA (*) 5: 0...20mA (*)		Configuration of analog input signal 2  <b>Note:</b> On i510 only unipolar voltage input available.			
<b>P431:2</b>	<b>0x2637:2</b>	<b>Analog input 2: Min value [Hz]</b>	i510	i550	R/W
-1000.0 ... [0.0] ... 1000.0 Hz		Frequency scaling of the analog input Represents the minimum of the analog input value			
<b>P431:3</b>	<b>0x2637:3</b>	<b>Analog input 2: Max value [Hz]</b>	i510	i550	R/W
-1000.0 ... [50.0] ... 1000.0 Hz		Frequency scaling of the analog input Represents the maximum of the analog input value			
<b>P431:4</b>	<b>0x2637:4</b>	<b>Analog input 2: Min value [Punit/%]</b>	i510	i550	R/W
-300.00 ... [0.00] ... 300.00 PUnit/%		PID/Torque scaling of the analog input Represents the minimum of the analog input value			
<b>P431:5</b>	<b>0x2637:5</b>	<b>Analog input 2: Max value [Punit/%]</b>	i510	i550	R/W
-300.00 ... [100.00] ... 300.00 PUnit/%		PID/Torque scaling of the analog input Represents the maximum of the analog input value			
<b>P431:6</b>	<b>0x2637:6</b>	<b>Analog input 2: Filter time</b>	i510	i550	R/W
0 ... [10] ... 10000 ms		Analog input filter time constant			


## 6 Function & parameter description

Group 4 – I/O setup

P431:7	0x2637:7	Analog input 2: Deadband	i510	i550	R/W
0.0 ... [0.0] ... 100.0 %		Configuration of the deadband such that any input value below this percentage will be treated as 0Hz. (In % of Max Input Value) Example: Deadband 10% of 50Hz: -10V ... 10V Deadband -5Hz ... 5 Hz 0 ... 10V Deadband 0Hz ... 5 Hz			
P431:8	0x2637:8	Analog input 2: Monitoring level	i510	i550	R/W
-100.0 ... [0.0] ... 100.0 %		Monitoring condition of the analog input			
P431:9	0x2637:9	Analog input 2: Monitoring action	i510	i550	R/W
0: Below level 1 1: Above level 1		Monitoring condition of the analog input			
P431:10	0x2637:10	Analog input 2: Error response	i510	i550	R/W
3:Fault (Reference see P310:1)		Fault reaction of the analog input monitoring.			

### 6.6.9 Analog output settings

The analog output can be used to send a feedback signal to the control system (i. e. Motor current, Actual Frequency, ...). Different functions and output configurations are available.



P440:1	0x2639:1	AO1 configuration	i510	i550	R/W
0: Disabled <b>1: 0...10VDC</b> 2: 0...5VDC 3: 2...10VDC 4: 4...20mA 5: 0...20mA		Configuration of Analog output signal 1			
P440:2	0x2639:2	Function	i510	i550	R/W
0: Not connected <b>1: Output frequency</b> 2: Frequency setpoint 3: Analog input 1 4: Analog input 2		Analog output function1  Scaling factors: 1: [0.1 Hz] 2: [0.1 Hz]			

## 6 Function & parameter description

### Group 4 – I/O setup

5: Motor current 6: Actual power 20: NETWordIN3 21: NETWordIN4	3: [0.1 %] 4: [0.1 %] 5: [0.1 A] 6: [0.001 kW] 20: [0.1 %] 21: [0.1 %]			
<b>P440:3</b>	<b>0x2639:3</b>	<b>Minimum signal</b>	<b>i510</b>	<b>i550</b>
-- ... [0] ... --		Minimum scaling of the analog output 1 Setting x Scaling factor = Minimum analog output value:  Example: Setting 10, 'Actual output frequency' Minimum analog output value = 10 x 0.1 Hz = 1Hz		R/W
<b>P440:4</b>	<b>0x2639:4</b>	<b>Maximum signal</b>	<b>i510</b>	<b>i550</b>
-- ... [1000] ... --		Maximum scaling of the analog Output 1 Setting x Scaling factor = Maximum analog output value:  Example: Setting 500, 'Actual output frequency' Maximum analog output value = 500 x 0.1 Hz = 50Hz		R/W

## 6 Function & parameter description

### Group 4 – I/O setup

#### 6.6.10 Preset setpoints (Frequency, PID)

The inverter has 15 preset frequency setpoints, 8 preset PID setpoints. They can be selected in two ways:

- As default setpoint (Frequency: P201:1, PID: P201:2)
- Triggered by digital inputs (P400:18 – 400:21)

The Preset setpoint selection is done by a binary combination of bits triggering the Preset Setpoint Selection Functions. Combination Example: bit0 and bit2 result in Preset 6



See chapter 6.2.1 Setpoint structure / operation mode, page 36

P450:1	0x2911:1	Preset 1	i510	i550	R/W
0.0 ... [20.0] ... 599.0 Hz		Preset frequency setpoint 1			
P450:2	0x2911:2	Preset 2	i510	i550	R/W
0.0 ... [40.0] ... 599.0 Hz		Preset frequency setpoint 2			
P450:3	0x2911:3	Preset 3	i510	i550	R/W
0.0 ... [Type code dependent] ... 599.0 Hz		Preset frequency setpoint 3			
P450:4	0x2911:4	Preset 4	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 4			
P450:5	0x2911:5	Preset 5	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 5 <b>Note:</b> Also used for Jog FWD			
P450:6	0x2911:6	Preset 6	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 6 <b>Note:</b> Also used for Jog REV			
P450:7	0x2911:7	Preset 7	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 7			
P450:8	0x2911:8	Preset 8	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 8			
P450:9	0x2911:9	Preset 9	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 9			
P450:10	0x2911:10	Preset 10	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 10			
P450:11	0x2911:11	Preset 11	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 11			
P450:12	0x2911:12	Preset 12	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 12			
P450:13	0x2911:13	Preset 13	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 13			
P450:14	0x2911:14	Preset 14	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 14			
P450:15	0x2911:15	Preset 15	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Preset frequency setpoint 15			
P451:1-8	0x4022:1-8	Process controller preset 1-8	i510	i550	R/W
-300.00 ... [0.00] ... 300.00 PUnit		Preset PID setpoint 1-8			

## 6 Function & parameter description

### Group 5 – Fieldbus

## 6.7 Group 5 – Fieldbus



See chapter 7 Fieldbus on page 95

## 6.8 Group 6 – PID setup


To regulate the motor speed related to a process value the inverter has a PID controller integrated. This is a closed loop control.

Example:

Using an feedback signal (i.e. pressure transducer) the inverter can regulate the speed.

### Setup procedure:

1. Select the correct PID Operating mode (P600:1)
2. Select the PID feedback source (P600:2) and setup the analog input accordingly
3. Select the PID default setpoint source (P201:2)
4. Set the PID speed range (P600:3) to a proper value
5. Test and tune your PID control  
(Start with default settings first)
6. Set additional functions (if needed)  
Setpoint ramp time, PID ramp time, Min/Max Alarm, line speed, influence function.



### 6.8.1 PID Setup

P600:1	0x4020:1	Operating mode	i510	i550	R/W
<b>0: Disabled</b> 1: Normal operation 2: Reverse operation 3: Normal bi-directional 4: Reverse bi-directional		PID Operating mode  0: Disabled: PID is disabled  1: Normal operation Direct acting system. Motor needs to increase the speed to increase the			

## 6 Function & parameter description

### Group 6 – PID setup

		feedback signal. Example: Booster pump regulated by Pressure. (Increase of Motor speed results in an increase of the pressure) Motor can turn only in one direction  2: Reverse operation Motor needs to increase the speed to decrease the feedback signal. Example: Cooling water pump regulated by temperature. (Increase of the cooling pump speed results in a decrease of the temperature.) Motor can run only in one direction  3: Normal bi-directional Normal acting mode. Motor can run in both directions.  4: Reverse bi-directional Reverse acting mode. Motor can run in both directions.	i510	i550	R/W
P600:2	0x4020:2	<b>Feedback source</b>	i510	i550	R/W
1: Analog input 1 2: Analog input 2 3: DC Bus voltage 4: Motor Current 5: Network		Selection of the PID feedback source <b>Note:</b> The PID set point and PID Feedback can be different signals!			
P600:3	0x4020:3	<b>Controlled speed range</b>	i510	i550	R/W
0 ... [100] ... 100 %		Defines the % of the inverter output frequency that PID will regulate to. Example: P211:0 Max frequency = 50 Hz P600:3 PID Controlled sped range = 80 % --> Max calculated PID setpoint 40 Hz			
P600:4	0x4020:4	<b>Speed feedforward source</b>	i510	i550	R/W
0: No Speed Added 1: Keypad frequency setpoint 2: Analog input 1 3: Analog input 2 4: Preset frequency setpoint 1 5: Preset frequency setpoint 2 6: Preset frequency setpoint 3 7: Preset frequency setpoint 4 8: Network		Selection of Speed feedforward source PID speed output = Speed feedforward source + PID controlled speed (Used for Trim control, Dancer control). The line speed (feed-forward) value is added to the calculated PID output frequency value (see PID block diagram above).			
P601:0	0x4048:0	<b>P component gain</b>	i510	i550	R/W
0.0 ... [5.0] ... 1000.0 %		PID controller P gain % of max Frequency that results from a 1% PID Error Example: PID Error = 20 PUnits P601:0 P component gain = 2% P211:0 Maximum frequency = 50Hz --> PID Output = PID Error * P Gain * (Maximum frequency / 100) --> PID Output = 10 Hz			
P602:0	0x4049:0	<b>I component reset time</b>	i510	i550	R/W
20 ... [400] ... 6000 ms		PID controller adjustment time Tn - Value "6000 ms" deactivates the I component. - With P400:47 the I Part can be disabled			

## 6 Function & parameter description

Group 6 – PID setup

P603:0	0x404A:0	D component gain	i510	i550	R/W
0.0 ... [0.0] ... 20.0 s		PID controller D gain % of max Frequency that results from of 1%/s change of the PID Error			
P604:0	0x404B:0	Setpoint ramp (PID)	i510	i550	R/W
0.0 ... [20.0] ... 100.0 s		PID Setpoint ramp up/down time (Time from Analog Min to Analog Max)			

### 6.8.2 PID triggers

P400:45	0x2631:45	Process controller off	i510	i550	R/W
0:Not connected (Reference see P400:1)		Switch off PID controller by external trigger <b>State:</b> TRUE: Inverter switched to velocity mode. FALSE: PID control is determined by P600:1 PID Operating mode			
P400:46	0x2631:46	PID output forced to 0	i510	i550	R/W
0:Not connected (Reference see P400:1)		Switch off PID controller output to zero <b>State:</b> TRUE: The output of the PID controller is forced to 0. FALSE: No action			
P400:47	0x2631:47	PID integrator disabled	i510	i550	R/W
0:Not connected (Reference see P400:1)		Disable PID Integrator by external Trigger			

### 6.8.3 PID Setpoint limits

P605:1	0x404E:1	Minimum setpoint	i510	i550	R/W
-300.00 ... [-300.00] ... 300.00 PUnit		Minimum limitation of the PID setpoint			
P605:2	0x404E:2	Maximum setpoint	i510	i550	R/W
-300.00 ... [300.00] ... 300.00 PUnit		Maximum limitation of the PID setpoint			

### 6.8.4 PID Acceleration / Deceleration

P606:1	0x4021:1	Acceleration time	i510	i550	R/W
0.0 ... [1.0] ... 3600.0 s		PID output Acceleration time (Time from 0 to Maximum frequency)			
P606:2	0x4021:2	Deceleration time	i510	i550	R/W
0.0 ... [1.0] ... 3600.0 s		PID output Deceleration time (Time from Maximum frequency)			

## 6 Function & parameter description

Group 6 – PID setup

### 6.8.5 PID Influence

The Influence of the PID can be ramped up / down with a external Trigger.

Example usage: Winding application.

P400:48	0x2631:48	PID influence ramps active	i510	i550	R/W
<b>1:Constant TRUE</b> (Reference see P400:1)		Activates PID influence ramp by external Trigger <b>States:</b> TRUE: Influence ramp time have no effect on PID <b>Transition states:</b> FALSE --> TRUE: Ramping up PID according P607:1 TRUE --> FALSE: Ramping down PID according P607:2			
P607:1	0x404C:1	Ramp up time	i510	i550	R/W
0.0 ... [5.0] ... 999.9 s		Ramp up time during switch ON of influencing (P400:48 PID influence ramps active) (Time from 0 to Maximum frequency)			
P607:2	0x404C:2	Ramp Down Time	i510	i550	R/W
0.0 ... [5.0] ... 999.9 s		Ramp down time during switch OFF of influencing (P400:48 PID influence ramps active) (Time from Maximum frequency to 0)			

### 6.8.6 PID Alarms

P608:1	0x404D:1	MIN alarm threshold	i510	i550	R/W
-300.00 ... [0.00] ... 300.00 PUnit		Minimum alarm of PID feedback signal If PID feedback signal is lower than Min alarm level the signal is activated. Signal can be used to switch Digital Output / Relays / Network Output (Selection 75-77)			
P608:2	0x404D:2	MAX alarm threshold	i510	i550	R/W
-300.00 ... [100.00] ... 300.00 PUnit		Maximum alarm of PID feedback signal If PID feedback signal is high than Min alarm level the signal is activated. Signal can be used to switch Digital Output / Relays / Network Output (Selection 75-77)			

### 6.8.7 PID Sleep/Rinse function

The PID has an integrated sleep & rinse function.

- **Sleep function:** Stop PID if there is no demand from the process
- **Rinse function:** Start the inverter periodically during sleep mode to prevent accumulation of deposits in the piping or the pump system.




See Easy starter for setup and more information

## 6 Function & parameter description

### Group 7 – Auxiliary Functions

## 6.9 Group 7 – Auxiliary Functions

### 6.9.1 Device functions (Factory reset, load/store parameter)



P700:1	0x2022:1	Load factory setting	i510	i550	R/W
0: Off / ready 1: On / start 2: In process 3: Action cancelled 4: No access 5: No access / disabled		All parameters are reset to the factory setting optimized for 50Hz or 60Hz line frequency. Line frequency is selected by type key of device.  <b>1: On / start</b> Start the reset to factory function <b>0, 2, 3, 4, 5:</b> Status of the reset to factory function  <b>Note:</b> possible when the inverter is inhibited.			
P700:3	0x2022:3	Save data into EPM	i510	i550	R/W
0: Off / ready (Reference see P700:1)		Saves RAM values to the USER section of the EPM			
P700:4	0x2022:4	Load data from EPM	i510	i550	R/W
0: Off / ready (Reference see P700:1)		Reload USER parameters from EPM to the RAM.			
P700:5	0x2022:5	Load OEM data from EPM	i510	i550	R/W
0: Off / ready (Reference see P700:1)		Reload OEM parameters from EPM to the RAM.			
P700:6	0x2022:6	Save OEM data to EPM	i510	i550	R/W
0: Off / ready (Reference see P700:1)		Saves RAM values to the OEM section of the EPM.			

## 6 Function & parameter description

### Group 7 – Auxiliary Functions

#### 6.9.2 Keypad setup

P701:0	0x2862:0	Keypad setpoints	i510	i550	R/W		
1 ... [1] ... 100		Defines the setpoint increment by pressing UP/DOWN buttons on the keypad. (Scaling: Frequency = 0.1, PID = 0,01)					
P702:0	0x4002:0	Speed display scaling	i510	i550	R/W		
0.00 ... [0.00] ... 650.00		User unit can be shown on the keypad during running of the motor. (Example: Calculated speed after gearbox) The scaling factor P702:0 defines the user unit: User unit = "Actual frequency" x P702:0 The scaled user unit is also shown in P101:0 (0x400D:0) <b>Note:</b> 0: Function disabled In PID mode the user unit has to be selected setting P703:0 to the scaled user unit (Set P703:0 = 0x400D0000)					
P703:0	0x2864:0	Keypad display	i510	i550	R/W		
0x0 ... [0x0] ... 0xFFFFF00		The parameter which is shown on the keypad during running of the motor can be configured. Format: 0xiiiiss00 (iiii = Index heximal, ss=subindex) <b>Note:</b> 0: Function disabled Only parameters from group 1 can be selected.					
P705:0	0x2863:0	Keypad language selection	i510	i550	R/W		
0: No Language 1: English 2: German		Selects the language of the Keypad					

#### 6.9.3 DC brake setup

DC Braking creates a braking torque by injecting DC current into the motor. This is useful to aid in decelerating a load that would otherwise take a long time due to inertia. It is also useful to lock the motor rotor either before starting or upon stopping.

The DC-Brake can be used as follow:

##### 1. Starting of the motor

DC-Brake can be selected as starting method in P203:1. At the starting of the motor the DC-Brake with the value of P704:1 is applied for the time defined in P704:2. After that the speed is ramped up.

##### 2. Stopping of the motor

If during stopping the motor frequency goes below the level P704:3 the inverter stops the speed deceleration and applies the DC Brake with the value of P704:1 is applied for the time defined in P704:2.

##### 3. Manually triggered (I.e. Digital IO)

The Trigger P400:5 activates the DC brake manually.

**Note:** The DC brake is ON as long as the function is triggered!

## 6 Function & parameter description


### Group 7 – Auxiliary Functions

#### **(i) NOTICE!**

##### **Motor failure or damage**

During DC-Brake the motor heats up.

- ▶ DC Braking should only be used in applications where the load is stopped infrequently and should only be applied for the minimum time required possible.



P400:5	0x2631:5	DC brake	i510	i550	R/W
<b>0:Not connected</b> (Reference see P400:1)		Manual DC Brake activation signal  <b>Level:</b> TRUE: DC brake will be active. FALSE: DC brake will be deactivated.			
P704:1	0x2B84:1	Current	i510	i550	R/W
0.0 ... [0.0] ... 200.0 %		DC Brake current as of % of motor rated current			
P704:2	0x2B84:2	Auto hold time	i510	i550	R/W
0.0 ... [0.0] ... 999.9 s		DC Brake time			
P704:3	0x2B84:3	Auto enable threshold	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Frequency Threshold to apply the DC Brake during deceleration of motor.			

## 6 Function & parameter description

### Group 7 – Auxiliary Functions

---

#### 6.9.4 Regenerative energy management

##### **0: Brake resistor (only 550)**

If the threshold voltage is exceeded the braking resistor is energized.

##### **1: Deceleration override**

The motor will stop decelerating momentarily if the threshold voltage threshold is exceeded. (Maximum 4 s)

##### **2: Resistor and deceleration override (only 550)**

Combination of brake resistor and deceleration override

##### **3: Compound and deceleration override**

Combination of compound brake and deceleration override

The compound is an alternative where the inverter will superimpose a temporary increase to the speed setpoint to force the drive to cycle between decelerating and accelerating to maintain control of the DC Bus. Compound braking will cause the regenerative energy to be bled off of the motor in the form of heat. This results in the motor temperature rising and must be used with care to not shorten the life of the motor.

##### **4: Resistor/compound/override (only 550)**

Combination of brake resistor compound brake and deceleration override.

#### **(i) NOTICE!**

##### **Brake resistor failure**

A wrong dimensioned brake resistor can lead to a component failure.

- ▶ Use the brake resistor specified for the inverter.
- ▶ Avoid thermal overload of the brake resistor
- ▶ Set the correct parameter for the braking resistor

#### **(i) NOTICE!**


##### **Thermal overload of the motor**

During compound braking the motor overload monitoring ( $I_{2xt}$ ) is not adapted. If the braking too frequently, there is a risk of the motor being thermally overloaded.

- ▶ Avoid long braking times using the compound braking.
- ▶ The Compound Braking function must not be used with vertical conveyors (hoists) or with active loads!

## 6 Function & parameter description

### Group 7 – Auxiliary Functions



## 6 Function & parameter description

### Group 7 – Auxiliary Functions

P706:1	0x2541:1	Operating mode	i510	i550	R/W
0: Brake resistor (*) <b>1: Deceleration override</b> 2: Resistor and decel. override (*) 3: Comp. and decel.override 4: Resistor/comp/override (*)		Selection of braking mode			
P706:2	0x2541:2	Active threshold	i510	i550	R
-- ... [Actual value] ... -- V		DC link voltage threshold at which the braking is activated. The threshold depends on the selected "Rated mains voltage" and parameter "Reduced threshold" (P706:3)			
P706:3	0x2541:3	Reduced threshold	i510	i550	R/W
0 ... [0] ... 100 V		The activation of the braking method is reduced by this parameter.			
P706:4	0x2541:4	Additional frequency	i510	i550	R/W
0.0 ... [0.0] ... 10.0 Hz		Additional Frequency for deceleration compound braking mode.			
P706:5	0x2541:5	Deceleration override time	i510	i550	R/W
0.0 ... [2.0] ... 60.0 s		Maximum time in deceleration override braking mode. If the DC-Voltage doesn't fall below in the defined time the inverter goes to fault state.			
P706:6	0x2541:6	Brake resistor response	i510	i550	R/W
<b>0: Off: Inverter disable / Error</b> 1: On: Disable/Off: Error 2: Off: Disable / On: Error 3: On: Disable / Error		Defines the behavior of the braking chopper in case of state Inhibit and Error. (Used for inverters connected over DC-Link)			
P707:2	0x2550:2	Resistance value	i510	i550	R/W
0.0 ... [Type Code dependent] ... 500.0 Ohm		Setup brake resistor Set the nominal resistance of the brake resistor			
P707:3	0x2550:3	Rated power	i510	i550	R/W
0 ... [Type Code dependent] ... 800000 W		Setup brake resistor Set the rated power of the brake resistor			
P707:4	0x2550:4	Maximum thermal load	i510	i550	R/W
0.0 ... [Type Code dependent] ... 100000.0 kW		Setup brake resistor Set the maximal thermal load of the brake resistor			
P707:7	0x2550:7	Thermal load	i510	i550	R
-- ... [Actual value] ... -- %		Actual thermal load of the braking resistor			
P707:8	0x2550:8	Warning level	i510	i550	R/W
50.0 ... [90.0] ... 150.0 %		If the actual thermal load of the braking resistor exceeds the defined level, the reaction in P707:10 is executed			
P707:9	0x2550:9	Error threshold	i510	i550	R/W
50.0 ... [100.0] ... 150.0 %		If the actual thermal load of the braking resistor exceeds the defined level, the reaction in P707:11 is executed			
P707:10	0x2550:10	Response to warning	i510	i550	R/W
<b>1:Warning</b> (Reference see P310:1)		Configuration of the brake resistor warning reaction			
P707:11	0x2550:11	Response to error	i510	i550	R/W
<b>3:Fault</b> (Reference see P310:1)		Configuration of the brake resistor error reaction			

## 6 Function & parameter description

Group 7 – Auxiliary Functions

### 6.9.5 Loss of Load Detection

A loss of load can be detected and function can be triggered. (Example: Relay)

→ See Easy starter for setup and more information

### 6.9.6 Motor Brake Control

The i500 has an integrated function to control a mechanical brake.

→ See Easy starter for setup and more information

### 6.9.7 Access protection

The write access to the parameter set can be fully or partially protected. Read access can't be prohibited. For that PIN1 and PIN2 are available

#### Enable access protection:

By setting a PIN (1-9999) the access protection is automatically set as follow:

Power ON Login with PIN1	→	Favorites only Full write access
Power ON Login with PIN2	→	No write access Full write access
Power ON Login with PIN1 Login with PIN2	→	No write access Favorites only Full write access

#### Login (Keypad)

The PIN is automatically requested if you enter the menu

#### Logout (Keypad)

Go out of the menu is logging you out automatically

#### Disable access protection:

1. Login
2. Set the corresponding PIN parameter back to 0 disables the access protection

P730:0	0x203D:0	Access protection PIN1	i510	i550	R/W
-1 ... [0] ... 9999		Configure PIN1 for access protection Setting PIN to 1-9999 enables the access protection Setting PIN to 0 disables the access protection			
P731:0	0x203E:0	Access protection PIN2	i510	i550	R/W
-1 ... [0] ... 9999		Configure PIN2 for access protection Setting PIN to 1-9999 enables the access protection Setting PIN to 0 disables the access protection			

#### NOTICE!

The Behavior from the keypad and PC tool are the same. If the PIN1/PIN2 is lost the only way to unlock the device is to reset the device back to factory settings with the SW-tool.

## **6 Function & parameter description**

Group 7 – Auxiliary Functions

---

### **6.9.8 Favorites setup**

The favorites menu can be freely configured.



See Easy starter for setup and more information

---

### **6.9.9 Multiple Parameter Set Setup**

The inverter can switch between 4 sets of 32 parameters. The 32 parameters can be freely configured.



See Easy starter for setup and more information

---

## 7 Fieldbus

### Group 7 – Auxiliary Functions

## 7 Fieldbus

### Enable Network

In order to control the drive from the network the 0x2631:37 (P400:37) Network enable needs to be set (Either setting “TRUE” or mapping to a digital input to trigger signal). Once it is asserted the drive enters the network control mode.

**i** It is important to note that in network control mode the following functions still are active:

- Inverter Enable 0x2361:1 (P400:1)
- Run/Stop 0x2361:1 (P400:2)
- Quick Stop 0x2361:3 (P400:3)
- Reset fault 0x2361:4 (P400:4)
- DC Brake 0x2361:5 (P400:5)
- Jog forward (CW) 0x2361:10 (P400:10)
- Jog reverse (CCW) 0x2361:11 (P400:11)

All other function triggers 0x2361:6-25 (P400:6-25) are not active while the drive is in the network control mode.

To select the network as setpoint source in network mode use the “Default setpoint source” (P201:1-2) or the corresponding control bits (AC Drive Control Word, C135 Control Word, NETWordIN1).

P400:37	0x2631:37	Network enable	i510	i550	R/W
<b>0: Not connected</b> 114: Netw.Ctrl activ (Other Reference see P400:1)		<p>Enables the network for control</p> <p>114: TRUE if AC Drive Control Control Word (0x400B:1) bit 5 is active</p> <p><b>State:</b> TRUE: Network is enabled FALSE: Network is disabled</p> <p><b>Note:</b> If Network is enabled (<b>Network enable 0x2631:37, P400:37</b> is HIGH) it is not mandatory that <b>Inverter enable (0x2361:1, P410:1)</b> or <b>Run/Stop (0x2361:2, P410:2)</b> are assigned to a digital input (DI1-7). They can be set to [1] Constant TRUE to Enable and Run the inverter without using digital inputs (DI1-7).</p>			

Several command words, status and setpoint are available to control the drive from remote:

- CIA402 (Predefined mapping) Used for EtherCAT/CAN
- AC drive profile (Predefined mapping) Used for EtherNet/IP
- Lenze Legacy (Predefined mapping)
- Netword IN/Out (Configurable mapping)



See chapter 8 Drive Profile on page 103 for details.

## 7 Fieldbus

CANopen quick start

### 7.1 CANopen quick start

The Can communicates with the drive over the COB-IDs. This COB-IDs access the RPDO and TPDO Registers which are mapped to the parameter registers.



Detailed information about dip-switch settings for Node address, baud rate, and network termination are described in the i500 Mounting and switch-on instructions.

1. Register the eds file into your CANOpen master's configuration software

2. Set an individual Node address:

i510: Parameter setting P510:1 (0x2301:1)

i550: Dip-Switches or Parameter setting P510:1 (0x2301:1)

3. Set the baud rate

i510: Parameter setting P510:2 (0x2301:2)

i550: Dip-Switches or Parameter setting P510:2 (0x2301:2)

4. Setup network termination and both network ends (Resistor)

i510: Install external 120 Ohm 1/4 W Resistor

i550: Dip-Switches setting

5. CANOpen Slave / Mini-Master

The CANOpen enter a Preoperational state upon boot-up. The CANOpen master send a NMT message to wake the drive up and the CANOpen goes to Operational state. The i500 can be configured as CANOpen Slave or Mini-Master. A "mini-master" will boot in an "operational" state and after the delay time programmed in 0x2301:4 (P510.4) will send out the NMT message to set all slaves on the network to the "operational" state.

6. Watchdog

Per Default the watchdog is enabled with P540:5 (0x1400:5) setting 100ms. (Setting 0 disables the watchdog)

For a safe operation it is highly recommended to have the watchdog enabled!

7. Save the parameters (Set P700:3, 0x2022:3=1) and power cycle the drive completely that the configuration takes effect.

8. For network control the following setup needs to be done:

(This can also be done with SDO messages)

- For network control the P400:37 (0x2631:37) "Network enable" need to be set.

- Set P201:1 (0x2860:1) "Default frequency setpoint" to the network

9. Change the mapping as followed:

Controller to the drive:

COB ID	Register	Accessed Parameter
0x200+nodeID	RPDO1, Entry 1	0x4008:1 NetWordIN1
0x200+nodeID	RPDO1, Entry 2	0x400B:3 Network Speed Setpoint [0.1 Hz]

Drive to the Controller

COB ID	Register	Accessed Parameter
0x180+nodeID	TPDO1, Entry 1	0x400A:1 NetWordOut1
0x180+nodeID	TPDO1, Entry 2	0x400C:3 Network Speed Actual [0.1 Hz]



The mapping can be easily done with a guided screen in Easy Starter (Version ≥ V1.9)

If the mapping is done over the master PLC the procedure under point 10-11 needs to be followed.

10. RPDO1 Mapping (Used to command the drive)

RPDO1 must first have its COB ID set and have the PDO unlocked so that its mapping can be changed.

To do so you must set bit 31 in 0x1400:1. This will unlock the PDO for editing (makes the PDO invalid).

**RPDO1 Default COB ID: 0x200+the node ID (hex)**

## 7 Fieldbus

### CANopen quick start

---

Example:

Node ID is 10 (0xA) mapping of RPDO1 should be changed

1. Unlock the mapping:  
COB ID = 0x200+A. Setting Bit 31  
Set 0x1400:1 to 0x8000020A
2. Set the number of mapped subindexes for RPDO1 = 0. This allows the default data mapping of the PDO to be changed.  
Set 0x1600:0 = 0
3. Set the data mapping for the first two bytes of RPDO1 to NetWordIN1:  
Set 0x1600:1 = 0x400080110.
4. Set the mapping of byte 3 and of RPDO1 to Network Speed Setpoint [0.1 Hz]  
Set 0x1600:2 = 0x400B0310.  
The second word of RPDO1 will now be the drive's speed command in 0.1 Hz (i.e. 412=41.2Hz, absolute value)
5. Set the number of mapped subindexes for RPDO1 = 2  
Set 0x1600:0 = 2
6. Set the timeout for RPDO1 monitoring value in milliseconds  
Set 0x1400:5 = msec, Fault reaction set in 0x2857:1
7. Lock mapping  
Bit31 of 0x1400:1 must be set back to 0. Write the COB ID back to 0x1400:1  
COB ID = 0x200+A (If required the COB ID can be set here individually)  
Set 0x1400:1 to 0x20A

#### 11. **TPDO1 Mapping (used to get status from the drive)**

TPDO1 must first have it's COB ID set and have the PDO unlocked so that it's mapping may be changed.

To do so you must set bit 31 in 0x1800:1. This will unlock the PDO for editing (makes the PDO invalid).

**TPDO1 Default COB ID: 0x180+the node ID (hex)**

(Note: Bit 30=Remote Frame OFF should be always set → 0x40000180)

Example:

Node ID is 10 (0xA) mapping of TPDO1 should be changed

1. Unlock the mapping:  
COB ID = 0x40000180+A. Setting Bit 31  
Writing 0xC000018A to 0x1800:1
  2. Set the number of mapped subindexes for RPDO1 = 0. This allows the default data mapping of the PDO to be changed  
Set 0x1A00:0 = 0
  3. Set the data mapping for the first two bytes of TPDO1 to NetWordOut1:  
Set 0x1A00:1 = 0x400A0110
  4. Set the mapping of byte 3 of TPDO1 to Network Speed Actual [0.1 Hz]  
Set 0x1A00:2 = 0x400C0310
  5. Set the number of mapped subindexes for TPDO1 = 2  
Set 0x1A00:0 = 2
  6. By default TPDO will transmit on event (0x1800:2 = 255). The event timer is default 20msec (0x1800:5 = 20) TPDO1 will be transmitted every 20msec.
  7. Lock mapping  
Bit31 of 0x1800:1 must be set back to 0. Write the COB ID back to 0x1800:1  
COB ID = 0x40000180+A (If required the COB ID can be set here individually)  
Set 0x1800:1 to 0x4000018A
12. Controlling the inverter:
- With the default IO-setting DI1 need to be asserted (Run/Stop).
  - Set Bit 4 of NetWordIN1 to start the drive

## 7 Fieldbus

CANopen quick start

Default setting of NetWordIN1 / NetWordOUT1 (SW 02.01)

Lenze control word (NetWordIN1)	
Bits	Function
0	Not connected
1	Not connected
2	Quick Stop
3	Not connected
4	Run forward (CW)
5	Preset bit0 selection
6	Preset bit1 selection
7	Reset Fault
8	Not connected
9	DC brake
10	Not connected
11	Not connected
12	Invert rotation
13	Not connected
14	Not connected
15	Not connected

Lenze status word (NetWordOUT1)	
Bits	Function
0	Ready for operation
1	Not connected
2	Inverter enable
3	Fault
4	Not connected
5	Quick stop active
6	Running
7	Device warning
8	Not connected
9	Not connected
10	Setpoint speed reached
11	At current limit
12	Actual speed = 0
13	Invert rotation
14	Holding brake release
15	Safe Torque Off

## 7.2 Modbus quick start

### 1. General Information about Modbus

The Can communicates with the drive over the Modbus-Register Numbers. This Number access the parameter registers.

The supports the following function codes:

- 3 (Read Holding Registers)
- 6 (Preset Single Register)
- 16 (10hex - Preset Multiple Registers)
- 23 - (17hex - Read/Write 4X registers)

**i** All data in Lenze drives is only accessible via Modbus as 4X holding registers.

In Modbus the function code used defines what the leading character in the Modbus address (so the leading 4 is not transmitted in the message).



It is important to note that Lenze complies with base 1 addressing of Modbus. So there is a 1 offset in the address transmitted to the address requested (i.e. 0000 would be register 40001, 0001 would be 40002, 0002 would be 40003, etc.).



By default important Parameters are already mapped to Modbus Registers

Modbus Control Parameters

Modbus Register No	Index	Description
42101	0x400B:1	Drive Command Word (AC Drive Control Word)
42102	0x400B:5	Network Frequency Setpoint ABS[0.01Hz]
42103	0x4008:2	NetWordIN2 (trigger for Digital / Relay Output)
42104	0x4008:3	NetWordIN3 (Analog output source)
42105	0x2DA7:0	Network PID Setpoint
42106	0x6071:0	Target Torque
42107	0x4008:1	NetWordIN1 (triggers for functions in PAR0400)
42108	0x4008:4	NetWordIN4(Analog output source)
42109 - 42121		Reserved

Modbus Drive Status Parameters (Read Only)

Modbus Register No	Index	Description
42001	0x400C:1	Drive Status Word (See bit details below)
42002	0x400C:6	Actual Frequency ABS [0.01Hz]
42003	0x603F:0	Error Code
42004	0x400C:0	Drive State
42005	0x2D89:0	Motor Voltage
42006	0x2D88:0	Motor Current
42007	0x6078:0	Motor Load
42008	0x2DA2:2	Effective power output [HIGH WORD]
42009		Effective power output [LOW WORD]

## 7 Fieldbus

### Modbus quick start

42010	0x2D84:1	Heatsink Temperature (Actual Value)
42011	0x2D87:0	DC Bus Voltage
42012	0x60FD:0 (Upper 16 bits only! – bits 16..31)	Digital Inputs
42013	0x6077:0	Torque Actual Value
42014 - 42021		Reserved



Detailed information about dip-switch settings for Node address, baud rate, data format and network termination are described in the i500 Mounting and switch-on instructions.

#### 2. Set an individual Node address

Default Address 1

i510: Parameter setting (P510:1, 0x2321:1)

i550: Dip-Switches or Parameter setting (P510:1, 0x2321:1)

#### 3. Set the baud rate:

Default: Auto Detect. First 5 – 10 messages will be lost!

i510: Parameter setting (P510:2, 0x2321:2)

i550: Dip-Switch b=0 AutoDetect

Dip-Switch b=1 Parameter setting (P510:2, 0x2321:2)

#### 4. Set the data Format:

Default: Auto Detect. First 5 – 10 messages will be lost!

i510: Parameter setting (P510.3, 0x2321:3)

i550: Dip-Switch a=0 AutoDetect

Dip-Switch a=1 Parameter setting (P510.3, 0x2321:3)

#### 5. Setup network termination and both network ends (Resistor)

i510: Install external 120 Ohm 1/4 W Resistor

i550: Dip-Switches setting

#### 6. Save the parameter with P700:3 (0x2022:3) and power cycle the drive completely that the configuration takes effect.

#### 7. For network control the following setup needs to be done:

- For network control the P400:37 (0x2631:37) "Network enable" need to be set.

- Set P201:1 (0x2860:1) "Default frequency setpoint" to the network



Per default the watchdog timeout response for the communication is set to fault (P515.1, 0x2858:1).

#### 8. With the default IO-setting DI1 need to be asserted (Run/Stop)

#### 9. Controlling the inverter:

Set the following bits on register 42101 (AC Drive control word) with function code 0x06 or 0x10 to start:  
0x61 (Bit0 - Run Forward, Bit5 - Network Control, Bit6-Network Setpoint)

#### 10. Set speed setpoint:

Set register 42102 (Network Frequency Setpoint ABS[0.01Hz]) with the setpoint with function code 0x06

Example: 1234 = 12.34 Hz

## 7 Fieldbus

### Profibus quick start

#### 7.3 Profibus quick start



Detailed information about network setup and dip-switch settings for Node address are described in the i500 Mounting and switch-on instructions.

1. Set an individual node address:  
i550: Dip-Switches or Parameter setting P510:1 (0x2341.1)  
The active node address will be displayed in P511:1 (0x2342.1)
  2. Save the parameters (P700:3, 0x2022:3) and power cycle the drive completely that the configuration takes effect.
  3. Configuration of the host:  
Read the device description file (GSD) into the Profibus master.
- i** The user data length is defined during the initialization phase of the master. The i500 support the configuration of a maximum of 16 process data words (max 32 bytes) in each direction.
4. Process data configuration  
The process data configuration must be configured in the Profibus master configuration tool.  
The default configuration in the i550 GSD-file is:

**PLC to Drive:**

Lenze control word (NetWordIN1) P590:1 (0x4008:1)  
Network frequency setpoint 0.01Hz P592:5 (0x400B:5)  
16Bit selectable OUT-Data

**Drive to PLC:**

Lenze status word (NetWordOUT1) P591:1 (0x400A:1)  
Actual Speed [0.01 Hz] P593:6 (0x400C:6)  
Actual motor current [0.1A] P104 (0x2D88)

Steckplatz	DP-Kennung	Bestellnummer / Bezeichnung	E-Adresse	A-Adresse
1	132	L-Controlword 0x4008:01		264...265
2	131	Net freq. 0.01Hz 0x400B:05		266...267
3	129	16Bit selectable OUT-Data		268...269
4	68	L-Statusword 0x400A:01	264...265	
5	67	Act.freq. 0.01Hz 0x400C:06	266...267	
6	67	Motor current A 0x2D88:00	268...269	



The configuration of the process data is automatically sent to the drive. Also the Bit-configuration of NetWordIN1 and NetWordOUT1.

## 7 Fieldbus

### Profibus quick start

The default setting for the Lenze control word (NetWordIN1) and Lenze status word (NetWordOUT1) are as follow (SW 02.01):

Lenze control word (NetWordIN1)	
Bits	Function
0	Not connected
1	Not connected
2	Quick Stop
3	Not connected
4	Run forward (CW)
5	Preset bit0 selection
6	Preset bit1 selection
7	Reset Fault
8	Not connected
9	DC brake
10	Not connected
11	Not connected
12	Invert rotation
13	Not connected
14	Not connected
15	Not connected

Lenze status word (NetWordOUT1)	
Bits	Function
0	Ready for operation
1	Not connected
2	Inverter enable
3	Fault
4	Not connected
5	Quick stop active
6	Running
7	Device warning
8	Not connected
9	Not connected
10	Setpoint speed reached
11	At current limit
12	Actual speed = 0
13	Invert rotation
14	Holding brake release
15	Safe Torque Off

5. For network control the following setup needs to be done:
  - For network control the P400:37 (0x2631:37) "Network enable" need to be set.
  - Set P201:1 (0x2860:1) "Default frequency setpoint" to the network
6. Controlling the inverter
  - With the default IO-setting DI1 need to be asserted (Run/Stop)
  - Set "Network frequency setpoint 0.01Hz", (Example 1234 = 12.34 Hz)
  - Set Bit 4 of "Lenze control word (NetWordIN1)" to start the drive



Per default the watchdog timeout response for the communication is set to fault (P515:1, 0x2859:1).


## 8 Drive Profile (Fieldbus)

Profibus quick start

# 8 Drive Profile (Fieldbus)

Several command words, status and setpoint are available to control the drive from remote:

- CIA402 (Predefined mapping) Used for EtherCAT/CAN
- AC drive profile (Predefined mapping) Used for EtherNet/IP
- Lenze Legacy (Predefined mapping)
- Netword IN/Out (Individual mapping)



## 8 Drive Profile (Fieldbus)

CIA402

### 8.1 CIA402

This chapter describes the CIA402 Format



This Format is normally used for EtherCAT and CAN



With default settings the Lenze-State machine is active. For full compatibility with CIA402 state machine the CiA402 mode needs to be selected in 0x6060. (Selection: [2] "Velocity mode CIA402")

For detailed description about CiA402 state machine refer to CiA402 documents.

#### 8.1.1 Control word

0x6040 CIA402 Drive Control Word

Bit	Function	Note
0	Switch on	0 = Switch inverter OFF 1 = Switch inverter ON
1	Enable voltage	0 = Disable Voltage 1 = Enable Voltage
2	Activate quick stop	0 = Quick stop active 1 = Quick stop not active
3	Enable operation	0 = Controller inhibit 1 = No controller inhibit
4	Operation mode specific	
5	Operation mode specific	
6	Operation mode specific	
7	Fault reset	Transition from 0 to 1 resets fault
8	n/a	
9	Operation mode specific	
10	Reserved	
11	Reserved	
12	Reserved	
13	Reserved	
14	Holding brake release	1 = Releases holding brake
15	Reserved	

## 8 Drive Profile (Fieldbus)

CIA402

---

### 8.1.2 Status word

0x6041:0      P780:0      CIA402 Drive Status Word

Bit	Function	Note
0	Ready to switch on	
1	Switched on	
2	Operation enabled	
3	Fault active	
4	Voltage enabled	
5	Quick stop	0 = Quick stop active 1 = Quick stop not active
6	Switch on disabled	
7	Warning active	
8	Deactivate RPDOs	
9	Remote	Network control mode active
10	Target reached	Target speed reached
11	Internal limit active	Internal limit of speed setpoint active
12	Reserved	
13	Reserved	
14	Brake released	
15	STO not active	

### 8.1.3 Speed setpoint / Actual Speed

P781:0	0x6042:0	Target velocity vl	i510	i550	R/W
-- ... [0] ... -- rpm		CiA402 network speed setpoint			

P783:0	0x6044:0	Velocity actual value vl	i510	i550	R
-- ... [Actual value] ... -- rpm		CiA402 actual speed			

## 8 Drive Profile (Fieldbus)

Legacy Lenze Format

### 8.2 Legacy Lenze Format

This chapter describes the Legacy Lenze Format.



This Format was used in other Lenze products such as 8200Vector and 8400

#### 8.2.1 Control word C135

0x400B:2      P592:2      Lenze Legacy C135 control word

Bits	Function	Comments
0	Setpoint Selection bit 0	Bits 0,1 decoding: 0 = Flexible (Default setpoint is active) 1 = Preset Setpoint #1
1	Setpoint Selection bit 1	2 = Preset Setpoint #2 3 = Preset Setpoint #3
2	Rotation (0-CW/1-CCW)	
3	Activate quick stop	0 = Not Active 1 = Active
4	Reserved	
5	Reserved	
6	Reserved	
7	Reserved	
8	Reserved	
9	Disable (1-active/0-inactiv)	0 = Controller released 1 = Controller Inhibited
10	Network user fault	
11	Fault reset (0→1)	0->1 edge causes TRIP reset
12	Reserved	
13	Reserved	
14	DC Brake Active	0 = Not Active 1 = Active
15	Reserved	

## 8 Drive Profile (Fieldbus)

Legacy Lenze Format

---

### 8.2.2 Status word

0x400C:2      P593:2      Lenze Legacy C150 status word

Bits	Function	Comments
0	Active Parameter Set	0 = Parameter Set 1 or 3 active 1 = Parameter Set 2 or 4 active
1	Power stage inhibited	0 = enabled 1 = inhibited
2	Current/torque limit reached	Current limit reached Torque limit reached (in Torque mode)
3	Frequency setpoint reached	
4	Ramp generator	Input = Output
5	Below Frequency threshold	Below Frequency threshold Qmin Index 0x4005 (f < 0x4005) Qmin
6	Actual frequency = 0	
7	Inhibit (1-activ/0-inactiv)	0 = Drive Enabled 1 = Drive Inhibited
8	Encode status bit 0	0000 = Initializing
9	Encode status bit 1	0001 = Mains Voltage Off
10	Encode status bit 2	0010 = Switch n Inhibited 0011 = Operation Inhibited
11	Encode status bit 3	0100 = Flying Restart 0101 = DC Brake Active 0110 = Operation Enabled 0111 = Message Active 1000 = FAULT
12	Over-temperature warning	
13	DC Bus overvoltage	
14	Rotation (0-CW/1-CCW)	
15	Ready for Operation	

## 8 Drive Profile (Fieldbus)

Legacy Lenze Format

0x400C:5 P593:5 Lenze Legacy drive state

Bits	Function	Comments
0	Fault Locked	
1	Fault	
2	Start Pending	
3	Identification Not Done	
4	Inhibit	
5	Stop	
6	Switching On Sequence	
7	Identification in Progress	
8	Running	
9	Acceleration	
10	Deceleration	
11	Deceleration Override	
12	DC Brake	
13	Flying Start	
14	Current Limit	
16	Sleep Mode	

### 8.2.3 Speed setpoint / Actual Speed

Several speed command formats are also available:

P592:3	0x400B:3	Network frequency setpoint	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Legacy network frequency setpoint Scaling: 0.1 Hz unsigned (direction information comes via control word)			
P592:4	0x400B:4	Network setpoint speed	i510	i550	R/W
0 ... [0] ... 50000 rpm		Legacy network speed setpoint Scaling: RPM unsigned (direction information comes via control word)			
P592:5	0x400B:5	Network setp. frequency	i510	i550	R/W
0.00 ... [0.00] ... 599.00 Hz		Legacy network frequency setpoint Scaling: 0.01 Hz unsigned (direction information comes via control word)			
P592:6	0x400B:6	Network speed setpoint	i510	i550	R/W
-599.0 ... [0.0] ... 599.0 Hz		Legacy network frequency setpoint Scaling: 0.1 Hz signed			

Several actual speed formats are also available:

P593:3	0x400C:3	Actual frequency Hz	i510	i550	R
-- ... [Actual value] ... -- Hz		Legacy actual frequency Scaling 0.1Hz, unsigned			
P593:4	0x400C:4	Actual motor speed RPM	i510	i550	R
-- ... [Actual value] ... -- rpm		Legacy actual speed Scaling RPM, unsigned			
P593:6	0x400C:6	Actual frequency	i510	i550	R
-- ... [Actual value] ... -- Hz		Legacy actual frequency Scaling 0.01Hz, unsigned			

## 8 Drive Profile (Fieldbus)

### AC Drive Profile

## 8.3 AC Drive Profile

This chapter describes the AC Drive Format



This Format is normally used for EtherNet/IP

### 8.3.1 Control word

0x400B:1      P592:1      AC Drive control word



Some of the bits will be ignored if bit5 **NetCtrl** bit is not set, see table below for details

Bits	Function	Comments
0	Run forward (CW)	Run Forward - see transition table below for exact logic <b>NOTE: Bit processed only when NetCtrl = 1</b>
1	Run reverse (CCW)	Run Reverse - see transition table below for exact logic <b>NOTE: Bit processed only when NetCtrl = 1</b>
2	Fault Reset (0 -> 1)	Reset existing fault. Only on transition from 0->1
3	Reserved	
4	Reserved	
5	Control from Network (NetCtrl)	If bit5 NetCtrl is 1 and Network Enable 0x2631:37 = 114 (Network ControlEnableRequest.Bit): All bits of this control word are processed.  If bit5 NetCtrl is 0 or Network Enable 0x2631:37 is not asserted: Control bits 0, 1, 12, 13, 14, 15 are NOT processed; their states are ignored and the drive is in local control with functions triggered by settings in 0x2631 (P400)
6	Network setpoint source	If NetRef = 1 Network Setpoint becomes active drive setpoint. Network Setpoint could be speed, frequency, PID setpoint or Torque setpoint  If NetRef = 0 Selected default setpoint 0x2860:1-2 (0x201:1-2) is active.  <b>Note:</b> Bit 6 can also be used to set network as setpoint source in terminal mode. See 0x2631:17 (P400:17)
7	Reserved	
8	Reserved	
9	Reserved	
10	Reserved	
11	Reserved	
12	Inhibit	<b>NOTE: Bit processed only when NetCtrl = 1</b>
13	Activate quick stop	<b>NOTE: Bit processed only when NetCtrl = 1</b>
14	PID off (1 – off)	<b>NOTE: Bit processed only when NetCtrl = 1</b>
15	DC Brake	<b>NOTE: Bit processed only when NetCtrl = 1</b>

## 8 Drive Profile (Fieldbus)

### AC Drive Profile

---

#### 8.3.2 Status word

0x400C:1 P593:1 AC Drive status word

Bits	Function	Comments
0	Fault/Trip	0 = No Fault 1 = Faulted
1	Warning active	
2	Running forward (CW)	0 = Not running Forward 1 = Running Forward
3	Running reverse (CCW)	0 = Not running Forward 1 = Running Forward
4	Ready	0 = NOT Ready 1 = Ready
5	Control from Network	0 = Local Control 1 = Network Control
6	Reference from Network	0 = Local Reference 1 = Network Reference
7	At Reference	0 = Setpoint not reached 1 = Setpoint reached
8	Profile State bit0	
9	Profile State bit1	
10	Profile State bit2	
11	Profile State bit3	
12	PID active	0 = PID NOT Active 1 = PID Active
13	Torque mode active	0 = NOT in Torque Mode 1 = Torque Mode Active
14	Current Limit reached	0 = NOT in Current Limit 1 = in Current Limit
15	DC Brake Active	0 = DC brake NOT active 1 = DC brake active

## 8 Drive Profile (Fieldbus)

### AC Drive Profile

**Drive State: Lenze CIA402 state machine to Ethernet/IP Drive State conversion table:**

CiA402 Plus State	AC Drive Profile Drive State
INIT (0, 1)	0 - Vendor Specific
NOT_READY_TO_SWITCH_ON (2)	1 = Startup
SWITCH_ON_DISABLED (3)	2 = Not_Ready
READY_TO_SWITCH_ON (4) SWITCHED_ON (5)	3 = Ready
OPERATION_ENABLED (6)	4 = Enabled
DISABLE_OPERATION (7) SHUT_DOWN (8) QUICK_STOP (9)	5 = Stopping
FAULTREACTION_ACTIVE (10)	6 = Fault_Stop
FAULT (11)	7 = Faulted

### 8.3.3 Speed setpoint / Actual Speed

Several speed command formats are also available:

P592:3	0x400B:3	Network frequency setpoint	i510	i550	R/W
0.0 ... [0.0] ... 599.0 Hz		Legacy network frequency setpoint Scaling: 0.1 Hz unsigned (direction information comes via control word)			
P592:4	0x400B:4	Network setpoint speed	i510	i550	R/W
0 ... [0] ... 50000 rpm		Legacy network speed setpoint Scaling: RPM unsigned (direction information comes via control word)			
P592:5	0x400B:5	Network setp. frequency	i510	i550	R/W
0.00 ... [0.00] ... 599.00 Hz		Legacy network frequency setpoint Scaling: 0.01 Hz unsigned (direction information comes via control word)			
P592:6	0x400B:6	Network speed setpoint	i510	i550	R/W
-599.0 ... [0.0] ... 599.0 Hz		Legacy network frequency setpoint Scaling: 0.1 Hz signed			

Several actual speed formats are also available:

P593:3	0x400C:3	Actual frequency Hz	i510	i550	R
-- ... [Actual value] ... -- Hz		Legacy actual frequency Scaling 0.1Hz, unsigned			
P593:4	0x400C:4	Actual motor speed RPM	i510	i550	R
-- ... [Actual value] ... -- rpm		Legacy actual speed Scaling RPM, unsigned			
P593:6	0x400C:6	Actual frequency	i510	i550	R
-- ... [Actual value] ... -- Hz		Legacy actual frequency Scaling 0.01Hz, unsigned			

## 8 Drive Profile (Fieldbus)

### NETword Configuration

## 8.4 NETword Configuration

Instead of using the predefined command and status word there are general NETWords can be configured.



Depending on the fieldbus the mapping can be done in the Slave (inverter) or in the Master (PLC).

Note: If the mapping is done in the Master (Example: PROFIBUS) the mapping in the Slave is overwritten!

### Master → Inverter (NETWordIn)

- NETWordIn1: Function trigger bit  
Value: 0x4008:1 (P590:1)  
Configuration: 0x400E:1 (P505:1-16)
- NETWordIn2: Switch digital outputs/relay  
Value: 0x4008:2 (P590:2)  
Configuration: 0x2643:1-3 (P420:1-3)
- NETWordIn3: Source for AO1/AO2  
Value: 0x4008:3 (P590:3)  
Configuration AO1: 0x2639:2 (P440:2)  
Configuration AO1: 0x263A:2 (P441:2)
- NETWordIn4: Source for AO1/AO2  
Value: 0x4008:4 (P590:4)  
Configuration AO1: 0x2639:2 (P440:2)  
Configuration AO1: 0x263A:2 (P441:2)

### Inverter → Master (NETWordOut)

- NETWordOut1: Drive Status bits  
Value: 0x400A:1 (P591:1)  
Configuration: 0x2635:10-25 (P420:10-25)
- NETWordOut2: Switched by Sequencer  
Value: 0x400A:2 (P591:2)  
Configuration: Sequencer parameter

## 8 Drive Profile (Fieldbus)

NETword Configuration

### 8.4.1 NETWordIn configuration

**Actual value:**

P590:1	0x4008:1	NETWordIN1	i510	i550	R/W		
--		Actual value of mappable network in word 1 bit collector (Trigger Function) --> Trigger mapping 0x400E1:16 (P505:1-16)					
P590:2	0x4008:2	NETWordIN2	i510	i550	R/W		
--		Actual value of mappable network in word 2 bit collector (Trigger for digital Outputs) --> Trigger mapping 0x2634:1-3 (P420:1-3)					
P590:3	0x4008:3	NETWordIN3	i510	i550	R/W		
0.0 ... [0.0] ... 100.0 %		Actual value of mappable network in word 3 (Source for Analog Output 1 and 2) --> Mapping 0x2639:2 (P440:2), 0x263A:2 (P441:2)					
P590:4	0x4008:4	NETWordIN4	i510	i550	R/W		
0.0 ... [0.0] ... 100.0 %		Actual value of mappable network in word 3 (Source for Analog Output 1 and 2) --> Mapping 0x2639:2 (P440:2), 0x263A:2 (P441:2)					

**Configuration:**

P505:1	0x400E:1	NETWordIN1.00	i510	i550	R/W
<b>0: Not connected</b>					
1: Inverter disabled		Function of Network Input Word Bit 0			
2: Stop					
3: Quick stop					
4: Reset fault					
5: DC brake					
8: Run forward (CW)					
9: Run reverse (CCW)					
13: Invert rotation					
14: AI1 setpoint selection					
15: AI2 setpoint selection					
17: Network setpoint selection					
18: Preset bit0 selection					
19: Preset bit1 selection					
20: Preset bit2 selection					
21: Preset bit3 selection					
39: Ramp 2 selection					
40: Load parameter set					
41: Parameter set 1 selection					
42: Parameter set 2 selection					
43: User-Netw. fault 1					
44: User-Netw. fault 2					
45: Process controller off					
46: Set PID output to 0					
47: PID integrator disabled					
48: PID influence ramps active					
P505:2	0x400E:2	NETWordIN1.01	i510	i550	R/W
<b>0:Not connected</b>					
(Reference see P505:0)		Function of Network Input Word Bit 1			

## 8 Drive Profile (Fieldbus)

NETword Configuration

<b>P505:3</b>	<b>0x400E:3</b>	<b>NETWordIN1.02</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>3:Quick stop</b> (Reference see P505:0)		Function of Network Input Word Bit 2			
<b>P505:4</b>	<b>0x400E:4</b>	<b>NETWordIN1.03</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0:Not connected</b> (Reference see P505:0)		Function of Network Input Word Bit 3 (SW 02.01: New Default)			
<b>P505:5</b>	<b>0x400E:5</b>	<b>NETWordIN1.04</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>8:Run forward (CW)</b> (Reference see P505:0)		Function of Network Input Word Bit 4 (SW 02.01: New Default)			
<b>P505:6</b>	<b>0x400E:6</b>	<b>NETWordIN1.05</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>18:Preset bit0 selection</b> (Reference see P505:0)		Function of Network Input Word Bit 5 (SW 02.01: New Default)			
<b>P505:7</b>	<b>0x400E:7</b>	<b>NETWordIN1.06</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>19:Preset bit1 selection</b> (Reference see P505:0)		Function of Network Input Word Bit 6 (SW 02.01: New Default)			
<b>P505:8</b>	<b>0x400E:8</b>	<b>NETWordIN1.07</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>4:Reset fault</b> (Reference see P505:0)		Function of Network Input Word Bit 7			
<b>P505:9</b>	<b>0x400E:9</b>	<b>NETWordIN1.08</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0:Not connected</b> (Reference see P505:0)		Function of Network Input Word Bit 8 (SW 02.01: New Default)			
<b>P505:10</b>	<b>0x400E:10</b>	<b>NETWordIN1.09</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>5:DC brake</b> (Reference see P505:0)		Function of Network Input Word Bit 9 (SW 02.01: New Default)			
<b>P505:11</b>	<b>0x400E:11</b>	<b>NETWordIN1.10</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0:Not connected</b> (Reference see P505:0)		Function of Network Input Word Bit 10			
<b>P505:12</b>	<b>0x400E:12</b>	<b>NETWordIN1.11</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0:Not connected</b> (Reference see P505:0)		Function of Network Input Word Bit 11			
<b>P505:13</b>	<b>0x400E:13</b>	<b>NETWordIN1.12</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>13:Invert rotation</b> (Reference see P505:0)		Function of Network Input Word Bit 12 (SW 02.01: New Default)			
<b>P505:14</b>	<b>0x400E:14</b>	<b>NETWordIN1.13</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0:Not connected</b> (Reference see P505:0)		Function of Network Input Word Bit 13			
<b>P505:15</b>	<b>0x400E:15</b>	<b>NETWordIN1.14</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0:Not connected</b> (Reference see P505:0)		Function of Network Input Word Bit 14			
<b>P505:16</b>	<b>0x400E:16</b>	<b>NETWordIN1.15</b>	<b>i510</b>	<b>i550</b>	<b>R/W</b>
<b>0:Not connected</b> (Reference see P505:0)		Function of Network Input Word Bit 15			

## 8 Drive Profile (Fieldbus)

NETword Configuration

### 8.4.2 NETWordOut configuration

**Actual value:**

P591:1	0x400A:1	NetWordOUT1	i510	i550	R		
Bit # description: 0: Mapping bit 0 1: Mapping bit 1 ...		Actual value of mappable network out word 1 bit collector (Status bits) --> Trigger mapping 0x2634:1-3 (P420:1-3)					
P591:2	0x400A:2	NetWordOUT2	i510	i550	R		
Bit # description: 0: Mapping bit 0 1: Mapping bit 1 ...		No mapping					

**Configuration:**

P420:10	0x2634:10	NETWordOUT1 - bit 0	i510	i550	R/W		
<b>51:Ready for operation</b> (Reference see P420:1)		Function of Network Bit 0					
P420:11	0x2634:11	NETWordOUT1 - bit 1	i510	i550	R/W		
<b>0:Not connected</b> (Reference see P420:1)		Function of Network Bit 1 (SW 02.01: New Default)					
P420:12	0x2634:12	NETWordOUT1 - bit 2	i510	i550	R/W		
<b>52:Inverter enable</b> (Reference see P420:1)		Function of Network Bit 2 (SW 02.01: New Default)					
P420:13	0x2634:13	NETWordOUT1 - bit 3	i510	i550	R/W		
<b>56:Fault</b> (Reference see P420:1)		Function of Network Bit 3					
P420:14	0x2634:14	NETWordOUT1 - bit 4	i510	i550	R/W		
<b>0:Not connected</b> (Reference see P420:1)		Function of Network Bit 4 (SW 02.01: New Default)					
P420:15	0x2634:15	NETWordOUT1 - bit 5	i510	i550	R/W		
<b>54:Quick stop active</b> (Reference see P420:1)		Function of Network Bit 5					
P420:16	0x2634:16	NETWordOUT1 - bit 6	i510	i550	R/W		
<b>50:Running</b> (Reference see P420:1)		Function of Network Bit 6 (SW 02.01: New Default)					
P420:17	0x2634:17	NETWordOUT1 - bit 7	i510	i550	R/W		
<b>58:Device warning</b> (Reference see P420:1)		Function of Network Bit 7					
P420:18	0x2634:18	NETWordOUT1 - bit 8	i510	i550	R/W		
<b>0:Not connected</b> (Reference see P420:1)		Function of Network Bit 8 (SW 02.01: New Default)					
P420:19	0x2634:19	NETWordOUT1 - bit 9	i510	i550	R/W		
<b>0:Not connected</b> (Reference see P420:1)		Function of Network Bit 9 (SW 02.01: New Default)					
P420:20	0x2634:20	NETWordOUT1 - bit 10	i510	i550	R/W		
<b>72:Setpoint speed reached</b> (Reference see P420:1)		Function of Network Bit 10					

## 8 Drive Profile (Fieldbus)

### NETword Configuration

P420:21	0x2634:21	NETWordOUT1 - bit 11	i510	i550	R/W		
<b>78:At current limit</b> (Reference see P420:1)		Function of Network Bit 11 (SW 02.01: New Default)					
P420:22	0x2634:22	NETWordOUT1 - bit 12	i510	i550	R/W		
<b>71:Actual speed = 0</b> (Reference see P420:1)		Function of Network Bit 12 (SW 02.01: New Default)					
P420:23	0x2634:23	NETWordOUT1 - bit 13	i510	i550	R/W		
<b>69:Inverse rotation</b> (Reference see P420:1)		Function of Network Bit 13 (SW 02.01: New Default)					
P420:24	0x2634:24	NETWordOUT1 - bit 14	i510	i550	R/W		
<b>115:Holding brake release</b> (Reference see P420:1)		Function of Network Bit 14 (SW 02.01: New Default)					
P420:25	0x2634:25	NETWordOUT1 - bit 15	i510	i550	R/W		
<b>55:Safe Torque Off</b> (Reference see P420:1)		Function of Network Bit 15 (SW 02.01: New Default)					

## 9 Troubleshooting

### 9.1 LED status display

The inverter has two LEDs (RDY = READY, ERR = ERROR) on the front cover to identify the status of the inverter:

RDY (Blue)	ERR (Red)	State
–	–	No supply voltage
 1 Hz	–	STO active
		STO active, warning active
 2 Hz	–	Inverter inhibited
		Inverter inhibited, DC Voltage not
		Inverter inhibited, Warning active
		Inverter inhibited, Fault active
3s ON / 1s OFF	–	PID Sleep Mode active
	–	Inverter released, drive running OR Quick Stop active
		Inverter released, drive running, Warning active
		Inverter released, Trouble reaction active

### 9.2 CAN LED status display

The LED CAN-RUN and CAN-ERR in combination indicate when the inverter is not yet active on the CAN-Bus.

CAN-RUN (Green)	CAN-ERR (Red)	State
–		Inverter not active on CAN-Bus / Bus OFF
		Automatic baud rate detection

In general the LED CAN-RUN indicates CANopen state

CAN-RUN (Green)	CANopen state
	Pre-Operational
	Operational
	Stopped

In general the LED CAN-ERR indicates error states:

CAN-ERR (Red)	CANopen error
	Warning Limit reached
	Node Guard Event
	Sync Message Error (Can only occur in state “Operational”)

## 9 Troubleshooting

### Modbus LED status display

The Modbus module has two LEDs (RDY = READY, ERR = ERROR) on the front cover to identify the status:

RDY (Green)	ERR (Red)	State
—	ANY	No reception / transmission
		Frame reception or transmission
ANY	—	No error
		Communication Fault
		Internal fault
		Automatic baud rate detection

### 9.4 Profibus LED status display

The profibus module has two LEDs (NS = Status, NE = ERROR) on the front cover to identify the status:

NS (Green)	NE (Red)	State
—	—	Fieldbus deactivated, not initialized, power off or Firmware download
		Connected to master PLC in RUN state, current state is "data exchange"
		Not connected, PLC STOP or no data exchange
		Incorrect setting of station address, operation with default values
		Watchdog expired
—		Unrecoverable fault
ANY		PROFIBUS parameterization error
		PROFIBUS configuration error

## 9 Troubleshooting


### Error history

## 9.5 Error history

### 9.5.1 Error History Keypad

Any time the inverter experiences an Error condition during operation it is captured in the inverter non-volatile memory. For historical Error tracking purposes the Errors can be viewed in P155.00. This parameter contains the actual Error codes, the time (in running hours) that the Error occurred and the count of Errors (in case of multiple instances of the same Error condition). The Error History will retain the 32 most recent Errors.

The data in the Error History is described below:



## 9 Troubleshooting

### Error messages

#### 9.5.2 Error History Easy Starter

	Opens the error logbook
	Reset the drive error

Logbook					
Time	Type	occurred in	CiA 402 error code	Text	Count
12:18:38:02	Error	Device	0x4310	motor temperature has reached error level	8
12:16:31:59	Error	Device	0xFF64	power stage communication is out of synchronization	1
12:16:31:55	Warning	Device	0xFF15	DC link circuit - undervoltage warning	0
12:16:31:55	Error	Device	0x3220	DC link circuit - undervoltage , 1V	1
12:16:31:55	Warning	Device	0xFF15	DC link circuit - undervoltage warning	1
12:15:02:09	Error	Device	0x4310	motor temperature has reached error level	10
12:14:30:25	Warning	Device	0xFF18	DC link circuit - overvoltage warning	1
12:14:26:35	Error	Device	0x4310	motor temperature has reached error level	1
12:14:26:20	Error	Device	0xFF64	power stage communication is out of synchronization	1
12:14:26:17	Error	Device	0x3220	DC link circuit - undervoltage , 1V	1
12:14:25:37	Error	Device	0x4310	motor temperature has reached error level	2
12:14:23:26	Error	Device	0xFF64	power stage communication is out of synchronization	1
12:14:23:23	Warning	Device	0xFF15	DC link circuit - undervoltage warning	0
12:14:23:23	Error	Device	0x3220	DC link circuit - undervoltage , 1V	1
12:14:23:22	Warning	Device	0xFF15	DC link circuit - undervoltage warning	1
12:05:56:20	Error	Device	0xFF53	connection list wrong connected (not safe manner)	2

Time	Time of the fault occurrence based on “Operation time (Control unit)” P150.03. If more than one fault of the same type is counted (Count >1) the first fault occurrence time is shown! [dd:hh:mm:ss]
Type	Error type (Warning, Error, Trouble)
Occurred in	Occurrence of the event
CiA 402 Error code	Error Code
Text	Error text
Count	Number of sequential fault occurrences

## 9.6 Error messages

Error (Hex)	Error (Dec)	Fault Type	Tool text	Description
0x2250	8784	Error	PU over current	Short circuit (device internal). Will be triggered by the following events: - Brake chopper over current - Power stage over current - Charge relay not closed
0x2320	8992	Error	Earth leak fault	Short circuit/earth leakage (device internal)
0x2340	9024	Error	Motor shorted	Short circuit (motor-side)
0x2350	9040	Configurable	i2t motor	Load level fault (I2t, thermal state). (P308:1-3)
0x2382	9090	Configurable	ixt Fault	Ixt fault. (P135:5)

## 9 Troubleshooting

### Error messages

0x2383	9091	Warning	Ixt Warning	Ixt warning
0x2387	9095	Error	Clamp timeout	Clamp responded too often
0x3120	12576	Error	Mains Phase fail	Main single phase fault
0x3210	12816	Error	DC Bus OV	DC link circuit overvoltage
0x3211	12817	Warning	Warn.DC Bus OV	DC link circuit overvoltage warning
0x3220	12832	Trouble	DC Bus UV	DC link circuit undervoltage
0x3221	12833	Warning	Warn.DC Bus UV	DC link circuit undervoltage warning
0x3222	12834	Warning	DC Bus on-UV	DC link voltage to low for power up
0x4210	16912	Error	PU Overtemp.	Power module overtemperature fault
0x4281	17025	Warning	Heats. fan error	Heat sink fan fault. Check heat sink fan
0x4285	17029	Warning	Warn.PU Overtemp	Power module overtemperature warning
0x4310	17168	Configurable	Overtemp. motor	Motor temperature has reached error level. (P309:2)
0x5112	20754	Warning	24V supply low	24V supply level critical
0x5380	21376	Error	Incomp. OEM HW	Control Unit HW OEM Type is not compatible with Power Unit HW OEM Type
0x6010	24592	Warning	Watchdog timeout	Watchdog time-out
0x618A	24970	Warning	Int. fan error	Internal fan fault
0x6280	25216	Error	P400 config err	Connection list wrong connected. <b>Start forward/reverse</b> and <b>Run forward/reverse</b> can't be used together. In <b>Flexible</b> control mode <b>Inverter enable</b> or <b>Run/Stop</b> must be assigned to a I/O. (Exception: Inverter is controlled from network, <b>Network enable</b> (P400:37) is HIGH)
0x6281	25217	Error	User fault 1	User fault 1 (Defined in P400:43)
0x6282	25218	Error	User fault 2	User fault 2 (Defined in P400:44)
0x6290	25232	Warning	Invert rotation	Reverse direction protection warning. (P304:0)
0x6291	25233	Error	Trouble overflow	Maximal allowed troubles exceeded. (P760:2-5)
0x62A0	25248	Error	AC User fault	AC control user fault
0x62A1	25249	Error	Netw.UserFault 1	Network user fault 1
0x62A2	25250	Error	Netw.UserFault 2	Network user fault 2
0x62B1	25265	Error	NetwordIN1 error	NetwordIN1 duplicate bit connection fault
0x7080	28800	Error	Assertionlevel	Last setting of Assertion level is different to stored parameter. Check setting of P410:1, save parameters and re-boot inverter.
0x7081	28801	Configurable	AI1 monitoring	Analog input 1 fault (P430:8-10)
0x7082	28802	Configurable	AI2 monitoring	Analog input 2 fault (P431:8-10)
0x70A1	28833	Warning	AO1 monitoring	Analog output 1 fault
0x70A2	28834	Warning	AO2 monitoring	Analog output 2 fault
0x7121	28961	Error	Pole posi error	Pole position identification fault
0x7180	29056	Configurable	Mot max current	Motor over current. (P353:1-2)
0x7385	29573	Warning	F.fdb spd limit	Feedback system: speed limit
0x7580	30080	Configurable	Diag TX error	Diagnosis transmit message ring buffer error (0x218B:0)
0x7581	30081	Configurable	Diag RX error	Diagnosis receive message ring buffer error (0x218B:0)
0x7680	30336	Warning	EPM full	There are to many parameters on the EPM.

## 9 Troubleshooting

### Error messages

				<b>Fault reaction:</b> The device will copy the current backup to the user block and won't overwrite the RAM data. <b>Troubleshooting:</b> Trigger the command P700:3. The device will erase the user block and create a new one with current RAM data.
0x7681	30337	Error	EPM not present	The EPM is not present. <b>Fault reaction:</b> Factory setting will load. The user is not able to reset this fault. <b>Troubleshooting:</b> Switch off the device, plug in an EPM and power up again.
0x7682	30338	Error	EPM invalid data	The user parameter setting is invalid. Both blocks (User and backup block) are invalid. <b>Fault reaction:</b> The user parameter setting has lost. The default values will be loaded automatically. <b>Troubleshooting:</b> Save again user parameters with P700:3. The default values will be stored to the EPM. The old user parameter set will be lost.
0x7684	30340	Warning	Save incomplete	The store command has been interrupted through an unexpected power down. The user data are not completely stored. <b>Fault reaction:</b> At power up, the data will load from backup and copied to user block (The backup is on a older condition). <b>Troubleshooting:</b> Check the parameter setting and store them again.
0x7686	30342	Error	Net.config.error	Fieldbus module configuration mismatch fault
0x7689	30345	Warning	OEM data invalid	One or more parameters are invalid or the OEM block is blank. <b>Fault reaction:</b> The user parameter set will load automatically. <b>Troubleshooting:</b> Save OEM parameter (P700:6). In this case, the user parameter set will be lost.
0x768A	30346	Error	Wrong EPM	EPM: EPM Type not match
0x7690	30352	Error	OEM CU not match	The FW version does not match to the current used EPM data. <b>Fault reaction:</b> The data will load to RAM. <b>Troubleshooting:</b> Factory setting need to be loaded (P700:1)
0x7691	30353	Error	PU Data not matc	The FW type does not match to the current used EPM data. <b>Fault reaction:</b> The data will load to RAM. <b>Troubleshooting:</b> Factory setting need to be loaded (P700:1)

## 9 Troubleshooting

### Error messages

0x7692	30354	Error	User CU not matc	New FW type detected. The FW type is compatible to the current used EPM.  <b>Fault reaction:</b> The data will load to RAM. <b>Troubleshooting:</b> Accept new FW type (P700:27) (Changes in parameter setting). Alternative: Load factory settings (P700:1).
0x7693	30355	Error	EPM PU size inco	The PU type does not match to the current used EPM data.  <b>Fault reaction:</b> The data will load to RAM. <b>Troubleshooting:</b> Factory setting need to be loaded (P700:1)
0x7694	30356	Error	EPM new PU size	New PU type detected. The PU type is compatible to the current used EPM.  <b>Fault reaction:</b> The data will load to RAM. <b>Troubleshooting:</b> Accept new PU type (P700:27) (Changes in parameter setting). Alternative: Load factory settings (P700:1).
0x7695	30357	Warning	InvalidChgovrCfg	One or more parameter are not usable for the parameter changeover.  <b>Fault reaction:</b> Parameter changeover is disabled. <b>Troubleshooting:</b> Check fault status in P756:1 and correct the wrong index indicated in P756:2.
0x7697	30359	Error	Param. lost	EPM data: Lost modified parameters because of 24V power-cycling
0x8112	33042	Configurable	TO expl. msg	Fieldbus - Timeout explicit message (P515:6)
0x8114	33044	Configurable	TO overall comm	Fieldbus - Overall communication timeout (P515:7)
0x8182	33154	Configurable	CAN bus off	CAN bus off. (0x2857:10)
0x8183	33155	Configurable	CAN bus warning	CAN warning. (0x2857:11)
0x8184	33156	Configurable	CAN heartb. C1	CAN heartbeat time-out consumer 1. (0x2857:5)
0x8185	33157	Configurable	CAN heartb. C2	CAN heartbeat time-out consumer 2. (0x2857:6)
0x8186	33158	Configurable	CAN heartb. C3	CAN heartbeat time-out consumer 3. (0x2857:7)
0x8187	33159	Configurable	CAN heartb. C4	CAN heartbeat time-out consumer 4. (0x2857:8)
0x8190	33168	Configurable	Watchdog timeout	Fieldbus watchdog expired. (P515:1)
0x8191	33169	Configurable	Cycl data error	Fieldbus disruption of cyclic data exchange. (P515:2)
0x8192	33170	Configurable	Net. Init. error	Fieldbus communication stack initialization error (P515:4)
0x8193	33171	Configurable	Inv. cyclic data	Fieldbus invalid cyclic process data. (P515:5)
0x81A0	33184	Warning	Modbus TX error	Modbus transmit message ring buffer error
0x81A1	33185	Configurable	Timeout Modbus	Modbus network time-out. (P515:1-2)
0x81A2	33186	Warning	Modbus request	Modbus wrong request from master
0x8286	33414	Configurable	PDO map error	Fieldbus PDO mapping error. (P515:3)
0x8291	33425	Configurable	Timeout RPDO1	CAN time-out Rx PDO 1 (0x2857:1)
0x8292	33426	Configurable	Timeout RPDO2	CAN time-out Rx PDO 2 (0x2857:2)

## 9 Troubleshooting

### Error messages

0x8293	33427	Configurable	Timeout RPDO3	CAN time-out Rx PDO 3 (0x2857:3)
0x8311	33553	Configurable	F.TrqExc	Max torque exceeded (P329:1)
0x9080	36992	Error	Keypad removed	Keypad removed fault
0xFF02	65282	Configurable	Brk Resistor OL	Brake resistor overload fault. (P707:9, P707:11)
0xFF05	65285	Error	STO error	Safety supervision fault
0xFF06	65286	Configurable	Motor overspeed	Motor over speed. (P350:1-2)
0xFF09	65289	Configurable	Mot.PhaseFailure	Motor phase failure (P310:1-3)
0xFF0A	65290	Configurable	Phase U failure	Motor phase failure phase U. (P310:1-3)
0xFF0B	65291	Configurable	Phase V failure	Motor phase failure phase V. (P310:1-3)
0xFF0C	65292	Configurable	Phase W failure	Motor phase failure phase W. (P310:1-3)
0xFF19	65305	Error	Motor ID fault	Motor parameter identification fault
0xFF36	65334	Configurable	BrkResistor OL	Brake resistor overload warning. (P707:8, P707:10)
0xFF37	65335	Error	Auto start disb	Automatic start was inhibited. Run/Start signal was present during Power-On and start was inhibited because of setting in P203:2. Remove Run/Start signal and reset fault
0xFF56	65366	Warning	Warn. Max. Freq	Max output frequency reached

For other faults reboot the inverter. If the problem can't be resolved contact LENZE.

## 10 Maintenance

The i500 inverter does not require any maintenance if the prescribed operating conditions are observed.

### 10.1 Routine inspections

#### NOTICE!

It is a good practice to check the inverter during a routine inspection of the drive system:

- ▶ Remove dust from inverter housing if necessary.
  - ▶ Check that ventilation slots are not covered or obstructed.
  - ▶ Check the condition and tightness of the electric connections.
  - ▶ The integrity of all earth / ground connections should be periodically checked.
- 

#### DANGER!

##### Dangerous electrical voltage

Possible death or severe injuries due to electrical shock.

- ▶ All inspection works on the inverter must only be carried out in the deenergised state.
  - ▶ After switching off the mains voltage, the capacitors in the inverter can still be charged. Observe the waiting time on the inverter label before commencing work.
- 

### 10.2 Product support

Lenze Service GmbH  
Breslauer Straße 3, D-32699 Extertal  
Germany

Phone: 0080002446877 (24h helpline)  
Fax: +49 5154 82-1112  
Email: [service.de@lenze.com](mailto:service.de@lenze.com)

## 11 Decommissioning

### 11.1 Safety instructions



#### ⚠️ WARNING!

##### Dangerous electrical voltage

An electrical shock can cause death or severe personal injury.

- ▶ Apply lockout/tagout procedures for decommissioning.
  - ▶ Connect/disconnect all pluggable inverter connections only in deenergised condition!
  - ▶ Only remove the inverter from the installation in completely deenergised state.
- 

### 11.2 Removal and disposal

Recycle metal and plastic materials of the inverter. Ensure professional disposal of assembled PCBs.



Observe all applicable national regulations for the disposal of waste electronic equipment.

---

 Lenze Drives GmbH  
Postfach 10 13 52, D-31763 Hameln  
Breslauer Straße 3, D-32699 Extertal  
Germany  
HR Lemgo B 6478

 +49 5154 82-0  
 +49 5154 82-2800  
 lenze@lenze.com  
 www.lenze.com

 Lenze Service GmbH  
Breslauer Straße 3, D-32699 Extertal  
Germany

 0080002446877 (24 h Helpline)  
 +49 5154 82-1112  
 service.de@lenze.com